# RENAULT

**2** Transmission

- 20A CLUTCH
- 21A MANUAL GEARBOX
- **SEQUENTIAL GEARBOX**
- 23A AUTOMATIC GEARBOX
- 29A DRIVESHAFTS

X85

**NOVEMBER 2009** 

**EDITION ANGLAISE** 

All rights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

<sup>&</sup>quot;The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which the vehicles are constructed".

## **CLIO III - Chapitre 2**

### **Contents**

Pages

20A	СLUТСН		21B SEQUENTIAL GEARBOX	
	Clutch: Precautions for the repair	20A-1	Sequential gearbox: Precautions for the repa	ir 21B-1
	Clutch: Specifications	20A-2	Pressure accumulator:	21B-2
	Pressure plate - Disc: Removal - Refitting	20A-5	Removal - Refitting Pump assembly reserve Removal - Refitting	
	Clutch thrust bearing: Removal - Refitting	20A-11	Electro-hydraulic unit: Removal - Refitting	21B-8
21A	MANUAL GEARBOX		Pump assembly: Remove Refitting	al - 21B-12
	Manual gearbox:		Solenoid valves: Remov Refitting	al - 21B-28
	Identification	21A-1	Engagement sensor: Removal - Refitting	21B-32
	Manual gearbox oils: Draining - Filling	21A-3	Actuator module: Remo	
	Manual gearbox: Specifications	21A-5	Refitting	21B-34
	Manual gearbox: Removal -		Gear selection sensor: Removal - Refitting	21B-54
	Refitting Input shaft lip seal: Removal	21A-12	Clutch position sensor: Removal - Refitting	21B-56
	- Refitting	21A-44	Solenoid valve assembl	
	Differential output seal: Removal - Refitting	21A-46	pressure sensor: Remo Refitting	val - 21B-58
	Reverse gear switch: Removal - Refitting	21A-52	Sequential gearbox eng speed sensor: Removal Refitting	
			Sequential gearbox:	21R-66

#### **Contents**

	_				
21B	SEQUENTIAL GEARBOX		23A	AUTOMATIC GEARBOX	
	Sequential gearbox converter: Removal - Refitting	21B-76		Automatic gearbox connector: Removal - Refitting	23A-43
	Sequential gearbox gear lever: Removal - Refitting	21B-78		Automatic gearbox converter: Removal - Refitting	23A-45
	Sequential gearbox oil: Specifications	21B-82		Differential seal: Removal - Refitting	23A-46
	Sequential gearbox: Bleeding	21B-84		Converter seal: Removal - Refitting	23A-47
	Electro-hydraulic unit: List and location of components	21B-86		J	
	I		29A	DRIVESHAFTS	
23A	AUTOMATIC GEARBOX			Driveshaft: Precautions for the repair	29A-1
	Automatic gearbox: Identification	23A-1		Front left-hand driveshaft: Removal - Refitting	29A-2
	Automatic gearbox oil: Draining - Filling	23A-2		Front right-hand driveshaft: Removal - Refitting	29A-9
	Automatic gearbox: Specifications	23A-5		Relay shaft bearing: Removal - Refitting	29A-20
	Automatic gearbox converter: Fault finding	23A-6		Front driveshaft gaiter, wheel side: Removal - Refitting	29A-21
	Automatic gearbox: Removal - Refitting	23A-7		Front right-hand driveshaft	23A-21
	Drive plate: Removal - Refitting	23A-21		gaiter, gearbox side: Removal - Refitting	29A-24
	Multifunction switch: Removal - Refitting	23A-24		Front left-hand driveshaft gaiter, gearbox side: Removal - Refitting	29A-27
	Multifunction switch: Adjustment	23A-27			
	Speed sensor: Removal - Refitting	23A-28			
	Pressure sensor: Removal - Refitting	23A-31			
	Hydraulic distributor: Removal - Refitting	23A-34			
	Flow control solenoid valve: Removal - Refitting	23A-40			
	Hydraulic distributor solenoid valves: Removal - Refitting	23A-42			

### Clutch: Precautions for the repair



Special tooling required			
Emb. 1518	Set of clutch plate centring mandrels		
Emb. 1780	Set of clutch plate centring mandrels.		

#### Before removing the clutch, check:

- The direction of fitting for the clutch plate.

#### Before refitting the clutch, check:

- The flywheel friction track (no scratches or blue stains),
- The crankshaft bearing (no sticking),
- The engine and gearbox seals (replace if necessary),
- The sliding action of the clutch plate on the output shaft,
- The guide of the thrust bearing and clutch fork (no wear or scratches).

#### **WARNING**

To prevent the clutch from juddering or slipping, do not grease the output shaft or the clutch plate hub.

#### **During refitting:**

Check the direction of the clutch plate.

Centre the clutch plate using the **(Emb. 1518)** or **(Emb. 1780)**.

Gradually torque tighten the clutch pressure plate bolts.

#### After refitting, check:


- The clutch play (for a cable operated vehicle),
- Bleeding of the hydraulic circuit (for vehicles with hydraulic controls).

# **CLUTCH Clutch: Specifications**



D4F, and 740 or 742 or 764

#### Pressure plate



Pressure plate part no: 180 CPOE 3300

#### **Drive plate**





Plate external diameter: 181.5 mm

Plate thickness: **6.7 mm**Number of splines: **26**Colour of springs (**3**): Grey

Colour of springs (4): Black

D4F, and 784 or 786

#### Pressure plate



Pressure plate part no.: 200 CPOE 3900

#### **Drive plate**




Plate external diameter: 200 mm

Plate thickness: 7 mm


# **CLUTCH Clutch: Specifications**



Number of splines: 26

F4R or K4J or K4M

#### Pressure plate



Pressure plate part no: 200 CPOEH 3900

#### **Drive plate**




Plate external diameter: 200 mm


Plate thickness: 6.9 mm

Number of splines: 26

Colour of springs: Grey

K9K


#### Pressure plate



108795

Pressure plate part no: 215 CPoVK 4400

#### **Drive plate**



102142

Plate outer diameter: 215 mm

# CLUTCH Clutch: Specifications

Plate thickness: **6.9 mm** 

Number of splines: 26

Colour of springs (1): Red and Black


Colour of springs (2): Grey

Plate outer diameter: 215 mm

Plate thickness: **6.7 mm**Number of splines: **26** 


M4R, and TL4

#### Pressure plate



102143

#### **Drive plate**



## CLUTCH Pressure plate - Disc: Removal - Refitting




D4F or K4J or K4M or K9K, and 750 or 752 or 760 or 762 or 766 or 768, and JH3 or JR5

Special tooling required			
Mot. 582-01	Flywheel locking tool.		
Emb. 1518	Set of clutch plate centring mandrels		

Tightening torques ♡		
pressure plate mount- ing bolts	20 N.m	
pressure plate mount- ing bolts	15 N.m	

#### **REMOVAL**

□ Remove the gearbox ( (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12) ).




□ Lock the engine using the (Mot. 582-01) (1).

☐ Remove the pressure plate mounting bolts (2).

☐ Remove the friction plate.

☐ Replace any faulty parts.

#### REFITTING



108798

#### WARNING

- Degrease the flywheel friction face.
- Clean the clutch shaft splines.
- Refit the assembly without lubricant.
- Position the clutch plate.
- ☐ Centre the clutch plate using the (Emb. 1518) (3).
- ☐ Screw into place gradually in a radial pattern.

#### D4F or K4J or K4M

- ☐ Torque tighten:
  - pressure plate mounting bolts (20 N.m),

K9K, and 750 or 752 or 760 or 762 or 766 or 768

- ☐ Torque tighten:
  - pressure plate mounting bolts (15 N.m),
- □ Remove the tool (Mot. 582-01).
- □ Refit the gearbox ( (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12)).

### Pressure plate - Disc: Removal - Refitting



F4R, and TL4

Special tooling required			
Mot. 582-01	Flywheel locking tool.		
Emb. 1780	Set of clutch plate centring mandrels.		


	Tightening torques	
mechanism bolts	mounting	20 N.m

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see ) (MR 392, 80A, Bat-
- ☐ Remove the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-**12**) .

#### **II - OPERATION FOR REMOVAL OF PART CONCERNED**




- □ Lock the engine using the (Mot. 582-01) (1).
- ☐ Remove the pressure plate mounting bolts (2).
- ☐ Remove the pressure plate and the friction plate.

#### REFITTING

#### I - REFITTING PREPARATION OPERATION

- ☐ Degrease the flywheel friction face.
- ☐ Clean the clutch shaft splines.

#### **II - REFITTING OPERATION FOR PART CONCERNED**



108798

- Position the clutch plate.
- ☐ Centre the clutch plate using the (Emb. 1780) (3).
- ☐ Fit the pressure plate.
- ☐ Gradually tighten the clutch pressure plate mounting bolts radially.
- ☐ Torque tighten the mechanism mounting bolts (20 N.m).

#### **III - FINAL OPERATION**

- ☐ Remove the (Mot. 582-01) and (Emb. 1780).
- ☐ Refit the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12).
- ☐ Connect the battery (see ) (MR 392, 80A, Battery).

## CLUTCH Pressure plate - Disc: Removal - Refitting



M4R, and TL4

Special tooling required				
Mot. 1677	Flywheel locking tool.			
Emb. 1780	Set of clutch plate centring mandrels.			


Tightening tord	ques 🗇
clutch mechanism bolts	initial torque: 15 Nm
clutch mechanism bolts	25 Nm

#### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see ) (MR 392, 80A, Battery).
- □ Remove the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12).


## II - OPERATION FOR REMOVAL OF PART CONCERNED



□ Lock the engine using tool (Mot. 1677) (1).



- ☐ Slide the bolts (2) out of the mechanism.
- ☐ Remove the mechanism.



117628

□ Remove the clutch plate (3).

#### **REFITTING**

#### I - REFITTING PREPARATION OPERATION


- ☐ Degrease the flywheel friction face.
- ☐ Clean the clutch shaft splines.

### Pressure plate - Disc: Removal - Refitting




M4R, and TL4


## II - REFITTING OPERATION FOR PART CONCERNED



- ☐ Position the clutch driven plate.
- ☐ Centre the clutch plate using tool (Emb. 1780) (4).



- ☐ Pretighten to torque and in order the clutch mechanism bolts (initial torque: 15 Nm).
- ☐ Torque tighten the clutch mechanism bolts (25 Nm).



#### Note:

Position the clutch plate with the section (5) against the flywheel.

#### **III - FINAL OPERATION**

- ☐ Remove the (Mot. 1677) and (Emb. 1780).
- □ Refit the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal Refitting, page 21A-12).
- ☐ Connect the battery (see ) (MR 392, 80A, Battery).

## CLUTCH Pressure plate - Disc: Removal - Refitting



K9K, and TL4

Special tooling required			
Mot. 582-01	Flywheel locking tool.		
Emb. 1780	Set of clutch plate centring mandrels.		


	Tightening torques ♡				
clutc	n pressure	plate	12 N.m		

#### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

 □ Remove the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12).


## II - OPERATION FOR REMOVAL OF PART CONCERNED



□ Lock the engine using the (1) (Mot. 582-01).



- ☐ Slide the bolts (2) out of the mechanism.
- ☐ Remove the mechanism.



117628

☐ Remove the clutch plate.

#### **REFITTING**

#### I - REFITTING PREPARATION OPERATION


- ☐ Degrease the flywheel friction face.
- ☐ Clean the clutch shaft splines.

### Pressure plate - Disc: Removal - Refitting




K9K, and TL4


## II - REFITTING OPERATION FOR PART CONCERNED



- ☐ Position the clutch plate.
- ☐ Centre the clutch plate using the (Emb. 1780).



☐ Tighten to torque and in order the clutch pressure plate bolts (12 N.m).



☐ Position the clutch plate with the section (10) against the flywheel.

#### **III - FINAL OPERATION**

- ☐ Remove the (Mot. 582-01) then the (Emb. 1780).
- □ Refit the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal Refitting, page 21A-12).

### Clutch thrust bearing: Removal - Refitting



#### 

bolts mounting the clutch thrust bearing on the clutch housing

21 Nm


The thrust bearing is connected to the clutch slave cylinder.

#### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

- ☐ Drain the brake reservoir using a syringe to remove the clutch thrust bearing and control.
- ☐ Remove the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-

#### II - REMOVAL OF PART CONCERNED



☐ Remove the two clutch thrust bearing mounting bolts (1) on the clutch housing.



108797

□ Remove the clutch thrust bearing (2).

#### **REFITTING**

#### I - REFITTING PART CONCERNED

- □ Refit the clutch thrust bearing (2).
- ☐ Torque tighten the bolts mounting the clutch thrust bearing on the clutch housing (21 Nm) (1).

#### **WARNING**

To avoid damaging the clutch slave cylinder, do not lubricate the clutch shaft.

Never operate the system while the slave cylinder is removed.

#### **II - FINAL OPERATION**

- ☐ Refit the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12).
- ☐ Bleed the clutch control (see Clutch circuit: Bleed) (MR 392, 37A, Mechanical component controls).

### Clutch thrust bearing: Removal - Refitting



TL4


Tightening torques ♡			
clutch bolts	thrust	bearing	21 Nm

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see ) (MR 392, 80A, Bat-
- ☐ Remove the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-

#### **II - OPERATION FOR REMOVAL OF PART CONCERNED**




116339

#### □ Remove:

- the bolts (1) from the clutch thrust bearing,
- the clutch thrust bearing.

#### REFITTING

#### I - REFITTING OPERATION FOR PART **CONCERNED**



116339

#### □ Refit:

- the new clutch thrust bearing,
- the bolts (2) from the clutch thrust bearing.
- ☐ Torque tighten the clutch thrust bearing bolts (21 Nm).


#### **II - FINAL OPERATION**


- ☐ Refit the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal - Refitting, page 21A-12).
- ☐ Connect the battery (see ) (MR 392, 80A, Battery).

JA3 or JA5 or JH3 or JR5

 $\rm K4J\,/\,K4M\,/\,K9K\,/\,D4F$  engines are fitted with type JH and JR manual gearboxes.


A marking (1) on the gearbox casing indicates:






(A) Gearbox type
(B) Gearbox suffix
(C) Production plant
(D) Production number

K9K, and TL4 - F4R, and 830, and TL4



- (1) Identification plate
- (2) Engraving



- Gearbox type
- (B) Gearbox suffix

(**A**)

- (C) Production plant
- (**D**) Production number

# MANUAL GEARBOX Manual gearbox oils: Draining - Filling



JH3 or JR5


#### Capacity (in litres)

JR5	2.5
JH3	2.8

#### **DRAINING**


- □ Remove:
  - the engine undertray mounting bolts,
  - the engine undertray.

JH3



☐ Remove the drain plug (1).

JR5



☐ Remove the drain plug (2).


#### **FILLING**

- ☐ It is essential to replace the drain plug seal.
- ☐ Refit the drain plug.

# MANUAL GEARBOX Manual gearbox oils: Draining - Filling


JH3 or JR5

JH3




□ Remove the filler cap (3).

JR5



☐ Remove the filler cap (4).



- ☐ Fill up to the level of the opening with oil recommended by the manufacturer (see **Manual gearbox oil: Specifications**) (Technical Note 6012A, 04, Lubricants).
- ☐ Refit the filler cap.
- ☐ Refit:
  - the engine undertray,
  - the engine undertray mounting bolts.

21A

JA3 or JA5 or JH3 or JR5

**GEAR RATIOS** 

Suffix	First	Second	Third	Fourth	Fifth	Reverse gear	Final drive	Tacho meter
	•	•	JA3 se	quential gearb	OOX	•	•	+
JA3-001	11/41	21/43	28/39	34/35	39/32	11/39	14/61	None
	•	•	JA5 se	quential gearb	OOX		•	•
JA5-001	11/41	21/43	28/37	35/34	41/31	11/39	16/55	None
		•	JH1 n	nanual gearbo	x		•	-1
JH1 -004	11/37	22/41	28/37	34/35	39/32	11/39	14/59	21/19
JH1 -013	11/37	22/41	28/37	34/35	39/32	11/39	15/61	21/19
JH1 -014	11/37	22/41	28/37	30/29	39/32	11/39	15/58	21/19
JH1 -015	11/37	22/41	28/37	30/29	41/31	11/39	15/56	21/19
JH1 -016	11/37	22/41	28/37	34/35	39/32	11/39	14/59	None
JH1 -017	11/37	22/41	28/37	34/35	39/32	11/39	15/61	None
JH1-019	11/37	22/41	28/37	34/35	39/32	14/59	14/59	21/19
JH1 -018	11/37	22/41	28/37	30/29	41/31	11/39	15/56	21/19
JH1 -020	11/41	21/43	28/39	34/35	39/31	11/39	14/59	None
JH1-021	11/41	21/43	28/39	34/35	39/31	11/39	14/59	None
JH1 -053	11/41	21/43	28/39	34/35	39/31	11/39	14/59	22/18
JH1-054	11/41	21/43	28/39	34/35	39/31	11/39	15/56	21/19
JH1-055	11/37	21/41	28/37	34/35	39/31	11/39	16/55	21/19
		•	JH3 n	nanual gearbo	x			•
JH3-050	11/41	21/43	28/39	34/35	39/31	11/39	15/56	21/19
JH3-052	11/41	21/43	28/39	34/35	39/32	11/39	14/59	22/18
JH3-053	11/37	22/41	28/37	30/29	42/41	11/39	15/58	22/18
JH3-054	11/41	21/43	28/37	30/29	41/31	11/39	14/63	22/18
JH3-055	11/41	21/43	28/37	30/29	39/31	11/39	14/63	22/18
JH3-056	11/41	21/43	28/37	30/29	41/31	11/39	14/61	22/18
JH3-057	11/41	21/43	28/39	34/35	39/31	11/39	14/59	None
JH3-058	11/41	21/43	28/39	34/35	39/32	11/39	14/59	22/18
JH3-059	11/45	22/47	28/39	34/35	37/33	11/39	14/69	22/18

**21A** 

Suffix	First	Second	Third	Fourth	Fifth	Reverse gear	Final drive	Tacho meter
JH3-060	11/41	21/43	28/39	34/35	39/31	11/39	14/59	22/18
JH3-061	11/41	21/43	28/39	34/35	39/31	11/39	14/61	22/18
JH3-062	11/41	21/43	28/39	34/35	39/31	11/39	14/61	22/18
JH3-063	11/41	21/43	28/39	34/35	39/32	11/39	14/61	22/18
JH3-064	11/41	21/43	28/39	34/35	39/32	11/39	14/59	22/18
JH3-065	11/41	21/43	28/39	34/35	39/32	11/39	14/59	22/18
JH3-066	11/41	21/43	28/29	34/35	39/31	11/39	14/63	22/18
JH3-067	11/37	22/41	28/37	34/35	39/32	11/39	14/63	22/18
JH3-068	11/41	21/43	28/39	34/35	39/32	11/39	14/59	22/18
JH3-071	11/41	21/43	28/37	30/29	39/31	11/39	14/63	22/18
JH3-072	11/41	21/43	28/37	34/35	39/32	11/39	14/59	22/18
JH3-105	11/41	21/43	28/39	31/34	37/33	11/39	14/59	None
JH3-106	11/41	21/43	28/39	34/35	39/32	11/39	14/63	None
JH3-128	11/41	21/43	28/39	34/35	39/32	11/39	14/61	None
JH3-129	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-131	11/41	21/43	28/39	31/34	37/33	11/39	15/58	None
JH3-132	11/37	22/41	28/37	30/29	42/41	11/39	15/58	None
JH3-137	11/41	21/43	28/39	31/34	37/33	11/39	14/59	None
JH3-141	11/37	22/41	28/37	30/29	42/41	11/39	15/58	None
JH3-142	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-143	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-144	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-145	11/37	22/41	28/37	30/29	42/31	11/39	16/57	None
JH3-150	11/37	22/41	28/37	30/29	42/41	11/39	15/58	None
JH3-154	11/41	21/43	28/39	31/34	37/33	11/39	16/61	None
JH3-155	11/41	21/43	28/39	31/34	37/33	11/39	15/58	None
JH3-156								
JH3-160	11/41	22/41	28/37	30/29	42/31	11/39	15/58	22/18
JH3-166	11/41	21/43	28/37	30/29	42/31	11/39	16/55	None
JH3-169	11/41	21/43	28/39	34/35	39/31	11/39	14/59	None

**21A** 

	1	1	1	1	1	1_	1	T
Suffix	First	Second	Third	Fourth	Fifth	Reverse gear	Final drive	Tacho meter
JH3-170	11/41	21/43	28/39	34/35	39/32	11/39	14/63	None
JH3-171	11/37	22/41	28/37	34/35	39/31	11/39	15/61	None
JH3-172	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-173	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-174	11/37	22/41	28/37	30/29	42/31	11/39	15/68	None
JH3-175	11/37	22/41	28/37	30/29	42/31	11/39	15/68	None
JH3-176	11/41	21/43	28/39	34/35	39/32	11/39	14/61	None
JH3-177	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None
JH3-179	11/41	21/43	28/39	31/34	37/33	11/39	15/68	None
JH3-183	11/41	21/43	28/39	34/35	39/32	11/39	14/59	None
JH3-184	11/41	21/43	28/39	34/35	39/32	11/39	15/58	None
JH3-185	11/41	21/43	28/39	34/35	39/32	11/39	15/58	None
JH3-186	11/41	21/43	28/39	34/35	39/32	11/39	15/58	None
JH3-187	11/41	21/43	28/39	34/35	39/32	11/39	15/58	None
JH3-189	11/37	22/41	28/37	30/29	42/31	11/39	15/56	None
JH3-190	11/37	22/41	28/37	30/29	42/31	11/39	15/56	None
JH3-193	11/41	21/43	28/37	30/29	42/31	11/39	16/55	None
JH3-199	11/41	21/43	28/39	34/35	39/32	11/39	14/59	None
JH3-309	11/41	21/43	28/39	34/35	39/32	11/39	15/58	None
JH3-312	11/41	21/43	28/37	30/29	42/31	11/39	16/57	None
JH3-313	11/41	21/43	28/37	30/29	42/31	11/39	16/57	None
JH3-315	11/41	21/43	28/37	30/29	42/31	11/39	16/57	None
JH3-321	11/41	21/43	28/39	34/35	39/31	11/39	14/59	22/18
	•	•	JR5 n	nanual gearbo	x	•	•	•
JR5-003	11/37	22/41	28/37	34/35	39/32	11/39	15/61	None
JR5-004	11/41	21/43	28/37	35/34	41/31	11/39	16/55	None
JR5-008	11/41	21/43	29/39	31/34	37/33	11/39	15/58	None
JR5-015	11/41	21/43	28/39	31/34	37/33	11/39	15/58	None
JR5-016	11/41	21/43	28/37	35/34	41/31	11/39	16/55	None
JR5-017	11/41	21/43	28/39	31/34	37/33	11/39	15/61	None

21A

Suffix	First	Second	Third	Fourth	Fifth	Reverse gear	Final drive	Tacho meter
JR5-018	11/37	22/41	28/37	34/35	39/32	11/39	15/61	None
JR5-113	11/41	21/43	28/37	35/34	41/31	11/39	16/57	None
JR5-116	11/41	21/43	28/37	35/34	41/31	11/39	16/55	21/19
JR5-124	11/41	21/43	28/37	35/34	41/31	11/39	16/55	None
JR5-126	11/37	21/41	28/37	35/34	42/31	11/39	15/58	21/19
JR5-144	11/37	21/41	28/37	35/34	42/31	11/39	15/58	21/18
JR5-145	11/41	21/43	28/37	35/34	41/31	11/39	16/55	21/19
JR5-147	11/41	21/43	28/37	35/34	42/31	11/39	15/58	22/18
JR5-149	11/41	21/43	28/39	31/34	42/31	11/39	15/58	22/18
JR5-151	11/41	21/43	28/37	35/34	39/31	11/39	14/63	22/18
JR5-152	11/41	21/43	28/37	35/34	39/32	11/39	14/63	None
JR5-156	11/41	21/43	28/37	35/34	39/32	11/39	15/58	None
JR5-158	11/41	21/43	28/37	35/34	42/31	11/39	15/61	22/18
JR5-165	11/41	21/43	28/37	35/34	42/31	11/39	14/69	22/18
JR5-166	11/41	21/43	28/37	35/34	42/31	11/39	16/57	22/18
JR5-168	11/41	21/43	28/37	35/34	41/31	11/39	14/69	None
JR5-169	11/41	21/43	28/37	35/34	42/31	11/39	14/73	22/18
JR5-170	11/41	21/43	28/37	35/34	42/31	11/39	14/69	22/18
JR5-171	11/41	21/43	28/37	35/34	39/32	11/39	14/63	None
JR5-172	11/41	21/43	28/39	31/34	37/33	11/39	14/63	22/18
JR5-173	11/41	21/43	28/37	35/34	39/32	11/39	14/61	None
JR5-175	11/41	21/43	28/37	34/35	39/32	11/39	15/56	None
JR5-176	11/41	22/41	28/37	35/34	42/31	11/39	15/56	None
JR5-183	11/41	21/43	28/37	35/34	39/32	11/39	14/59	None
JR5-184	11/41	21/43	28/37	35/34	39/32	11/39	15/58	None
JR5-185	11/41	21/43	28/37	35/34	41/31	11/39	17/56	None
JR5-187	11/41	21/43	28/37	35/34	39/32	11/39	14/69	None
JR5-189	11/41	21/43	28/37	35/34	41/31	11/39	14/59	None
JR5-193	11/41	21/43	28/37	35/34	41/31	11/39	1756	None
JR5-301	11/41	21/43	28/37	35/34	41/31	11/39	15/56	None

**21A** 

Suffix	First	Second	Third	Fourth	Fifth	Reverse gear	Final drive	Tacho meter
JR5-302	11/41	21/43	28/37	35/34	41/31	11/39	14/69	None
JR5-308	11/41	21/43	28/37	31/29	45/31	11/39	18/57	None

## MANUAL GEARBOX

Manual gearbox: Specifications

21A

TL4

#### **GEAR RATIOS**

Suffix	1st	2nd	3rd	4th	5th	6th	Final drive	Reverse gear
000	11/41	19/37	31/41	40/39	38/29	47/30	15/59	11/28
001	11/41	19/37	31/41	40/39	38/29	47/30	15/56	11/28
002	11/41	19/37	31/41	40/39	38/29	47/30	16/57	11/28
003	11/35	19/37	29/43	34/41	38/39	39/34	16/69	11/23
008	11/37	19/37	28/39	35/39	35/32	43/33	15/59	11/25
013	11/41	19/37	31/41	40/39	38/29	47/30	15/59	11/28
014	11/41	19/37	31/41	40/39	38/29	47/30	15/59	11/28
015	11/41	19/40	31/45	35/39	35/32	43/33	16/71	11/28
016	11/41	19/40	31/45	35/39	35/32	43/33	16/71	11/28
017	11/37	19/37	28/39	35/39	35/32	43/33	16/69	11/25
018	11/41	19/37	31/41	40/39	38/29	47/30	16/66	11/28
019	11/41	19/40	31/45	35/39	35/32	43/33	15/71	11/28
020	11/41	19/40	31/45	35/39	35/32	43/33	16/71	11/28
021	11/41	19/40	31/45	35/39	35/32	43/33	15/71	11/28
022	11/41	19/37	31/41	40/39	38/29	47/30	15/59	11/28
024	11/35	19/37	29/43	34/41	35/34	37/30	16/69	11/23
026	11/41	19/37	29/43	40/39	38/29	47/30	15/59	11/28
027	11/41	19/37	31/41	40/38	39/29	47/30	14/59	11/28
028	11/41	19/40	31/45	35/28	39/34	41/30	14/64	11/28
029	11/41	19/40	31/45	38/39	35/32	43/33	15/71	11/28
030	11/41	19/40	31/45	35/39	35/32	41/30	16/71	11/28
031	11/37	19/40	27/41	34/41	35/34	37/30	16/69	11/23
032	11/37	19/37	28/39	35/39	35/32	43/33	16/66	11/28
033	11/37	19/37	28/39	35/39	35/32	43/33	16/69	11/28
034	11/41	19/37	31/41	40/39	38/29	47/30	16/66	11/39
035	11/41	19/40	31/45	35/39	35/32	43/33	16/69	11/28
036	11/41	19/40	31/45	35/38	39/34	41/30	14/64	11/28
037	11/41	19/40	31/45	35/28	39/34	41/30	15/71	11/28

### **MANUAL GEARBOX**

Manual gearbox: Specifications

21A

TL4

Suffix	1st	2nd	3rd	4th	5th	6th	Final drive	Reverse gear
038	11/41	19/40	31/45	35/39	35/32	43/33	14/64	11/28
039	11/37	19/37	28/39	35/39	35/32	43/33	16/69	11/25
040	11/41	19/37	31/41	40/39	38/29	47/30	15/56	11/28
041	11/41	19/37	31/41	40/39	38/29	47/30	16/66	11/39
042	11/41	19/40	31/45	35/39	35/32	41/30	15/71	11/39
045	11/41	19/37	31/41	40/39	38/29	47/30	15/59	11/28



JH3 or JR5

Equipment required	
component jack	

Tightening torques ▽	
lower gearbox bell housing bolts	44 N.m
upper gearbox bell housing bolts	44 N.m

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION


☐ Position the vehicle on a two-post lift (see **Vehicle**: **Towing and lifting**).


#### **IMPORTANT**

During this operation, secure the vehicle to the lift with a strap, to avoid any imbalance.

For strapping the vehicle (see **02A**, **Lifting equipment**, **Vehicle: Towing and lifting**).

- ☐ Remove:
  - the battery (see Battery: Removal Refitting),
  - the battery tray (see ),
  - the air inlet duct,
  - the air filter unit (see Air filter unit: Removal Refitting) ,
  - the front wheels (see **Wheel: Removal Refitting**)
  - -the front wheel arch liners (see MR 393 Bodywork, 55A, Exterior protection, Front wheel arch liners: Removal Refitting).
  - the engine undertray.
- □ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).





#### □ Remove:


- the gear control cables from the gearbox by pressing at  $(\mathbf{A})$ ,
- the gearbox control cable sleeve stops by pressing at (**B**) .
- ☐ Disconnect the anti-lock braking system sensor connectors.

#### □ Remove:

 the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2),


JH3 or JR5

- -the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).
- ☐ Attach the radiator assembly to the upper cross member.
- □ Remove the radiator support cross member (see MR 393 Bodywork, 41A, Front lower structure, Radiator support cross member: Removal - Refitting).



1082

☐ Remove the engine tie-bar with its reinforcement (see Lower engine tie-bar: Removal - Refitting).



#### □ Remove:

- the reverse gear connector (15) on the gearbox,
- the earth strap (16) from the gearbox.

#### □ Remove:

- the starter (see Starter: Removal Refitting),
- the TDC sensor,
- the cover of the Protection and Switching Unit,
- the injection computer (see **Petrol injection computer: Removal Refitting**) ,
- the computer bracket mounting bolts bolts,
- the computer bracket.

### **MANUAL GEARBOX**


### Manual gearbox: Removal - Refitting

21A

JH3 or JR5



- ☐ Remove the mounting bolts (7) for the wiring duct on the body.
- ☐ Remove the wiring duct.
- ☐ Fit a hose clamp between the brake fluid reservoir and the clutch master cylinder.




109157

- □ Disconnect the clutch slave cylinder by pulling on the clips (8), (9).
- ☐ Collect the fluid in a container.
- ☐ It is essential to place protective plugs in the ends of the hoses.

#### □ Remove:

- the scuttle panel grille (see MR 393 Bodywork, 56A, Exterior protection, Scuttle panel grille: Removal - Refitting).
- the scoop under the scuttle panel grille (see 393 56A, Exterior equipment, Scoop under scuttle panel grille: Removal - Refitting).
- the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting).



109154

#### ☐ Remove:

- the bolts (12) securing the gearbox support.
- the gearbox support.

## II - OPERATION FOR REMOVAL OF PART CONCERNED


- ☐ Remove the upper gearbox bell housing bolts.
- ☐ Position the **component jack** under the gearbox.

### MANUAL GEARBOX

### Manual gearbox: Removal - Refitting



JH3 or JR5




#### □ Remove:

- the flywheel cover (13),
- the lower gearbox bell housing bolts,
- the gearbox mounting studs,
- the gearbox.

#### REFITTING

#### I - REFITTING PREPARATION OPERATION



☐ Check that the engine / gearbox centering rings (14) are present and correctly positioned.

#### **WARNING**

Do not grease:

- the transmission output shaft, so as not to damage the clutch slave cylinder,
- the clutch shaft splines.

#### Note:

- To avoid leaks, the clutch slave cylinder must always be replaced after the clutch pressure plate is replaced;
- Always replace the right-hand driveshaft circlip with a new one whenever it is removed.
- It is essential to replace the differential seals with new ones every time the driveshafts are removed.

## II - REFITTING OPERATION FOR PART CONCERNED

#### ☐ Refit:

- the gearbox,
- the gearbox mounting studs,

21A

#### JH3 or JR5

- the lower gearbox bell housing bolts, - the flywheel cover. ☐ Tighten to torque the lower gearbox bell housing bolts (44 N.m). ☐ Remove the **component jack** from underneath the gearbox. ☐ Refit the upper gearbox bell housing bolts. ☐ Tighten to torque the upper gearbox bell housing bolts (44 N.m). **III - FINAL OPERATION** ☐ Refit: -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting), -the scoop under the scuttle panel grille (see 393 56A, Exterior equipment, Scoop under scuttle panel grille: Removal - Refitting). -the scuttle panel grille (see MR 393 Bodywork, 56A, Exterior protection, Scuttle panel grille: Removal - Refitting). ☐ It is essential to remove the protective plugs from the ends of the hoses. ☐ Connect the clutch slave cylinder. ☐ Remove the hose clamp between the brake fluid reservoir and the clutch master cylinder. □ Refit: - the wiring channel on the body, - the mounting bolts for the wiring duct on the body. - the earth strap on the gearbox, - the computer mounting, - the computer bracket mounting bolts bolts,
- ☐ Detach the radiator assembly from the upper cross member.
- ☐ Refit:
  - the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2),
  - the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).
- Connect the ABS sensor connectors.
- □ Connect:
  - the gearbox control cable sleeve stops on the gearbox,
  - the gear control cables to the gearbox.
- ☐ Fill the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- Refit:
  - the engine undertray,
  - the front wheel arch liners (see MR 393 Bodywork, 55A, Exterior protection, Front wheel arch liners: Removal Refitting).
  - the front wheels (see **Wheel: Removal Refitting**)
  - the air filter unit (see Air filter unit: Removal Refitting) ,
  - the air inlet duct,
  - the battery tray (see ),
  - the battery (see Battery: Removal Refitting) .

- the engine tie-bar with its reinforcement (see Low-

- the injection computer (see Petrol injection com-

- the reverse gear connector on the gearbox,

- the cover of the Protection and Switching Unit,

- the starter (see Starter: Removal - Refitting) ,

er engine tie-bar: Removal - Refitting),

puter: Removal - Refitting),

-the TDC sensor,



K9K, and TL4

	Special tooling required
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.
Bvi. 1718	Component support plate for removal - refitting of gear-boxes.

Equipment required
safety strap(s)
component jack

Tightening torques	
nuts on the studs	44 Nm
gearbox bolts	44 Nm
exhaust strut bolt on the gearbox	21 Nm
exhaust strut nut on the gearbox	21 Nm
exhaust strut bolt on the catalytic converter	21 Nm
front axle subframe front left-hand bolt	105 Nm
tie-rod bolt	21 Nm
side stiffener bolts	21 Nm

#### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).


#### □ Remove:

- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),

- the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture).
- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the engine undertray,
- the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection),
- ☐ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).

#### □ Remove:

- the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
- the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9).




#### ☐ Remove:


- the side stiffener bolts (1),
- the front axle sub-frame front left-hand bolt (2),
- the tie-rod bolt (3),
- the tie rod (4) .

K9K, and TL4

#### K9K, and 772



- □ Remove:
  - the earth wiring bolt (5),
  - -the bolt (6) from the heating element and coolant pump support on the radiator mounting cross member.
- ☐ Disconnect the connector (7) from the heating element unit.
- ☐ Move the heating element and coolant pump support on the radiator mounting cross member to one side
- ☐ Undo the radiator mounting cross member bolts (see Radiator mounting cross member: General description) (MR 393, 41A, Lower structure).



- ☐ Attach the « cooling radiator fan unit » assembly to the upper cross member using a **safety strap(s)**.
- ☐ Remove the radiator mounting cross member (see Radiator mounting cross member: Removal Refitting) (MR 393, 41A, Front lower structure).
- □ Remove the rear suspended engine mounting (see Lower engine tie-bar: Removal - Refitting) (MR 392, 19D, Engine mounting).


#### **IMPORTANT**

Having already removed the driveshafts, remove the front axle subframe without removing the lower ball joint nuts.

☐ Remove the front axle sub-frame (see Front axle subframe: Removal - Refitting) (MR 392, 31A, Front axle components).

21A

K9K, and TL4




☐ Remove the earth wiring bolt (8).

#### Note:

Before removing the earth terminal, mark its position using an indelible marker by drawing a line on the earth terminal and on the gearbox casing.

When reassembling, improper positioning of the earth terminal on the gearbox casing could result in damage to the earth terminal or earth wiring.




#### □ Remove:


- the bolt and the nut (9) on the gearbox,
- the bolt (10) on the catalytic converter,
- the exhaust strut (11) .

K9K, and TL4

#### K9K, and 772




- ☐ Disconnect the connector (12) from the diesel injector.
- ☐ Remove the bolt (13) from the diesel injector wiring harness strut.
- ☐ Move the diesel injector wiring harness strut to one side.



#### ☐ Unclip:

- the gear control cables (14) from the gearbox using an open ended wrench,
- the gear control cable sleeve stops (15) from the gearbox,
- the expansion bottle (see Expansion bottle: Removal Refitting) (MR 392, 19A, Cooling).




- ☐ Remove the bolt (16) from the wiring harness channel on the gearbox.
- ☐ Remove the wiring harness channel.

#### K9K, and TL4

- □ Remove:
  - the starter (see **Starter: Removal Refitting**) (MR 392, 16A, Starting Charging),
  - -the engine speed and position sensor (see **Crank-shaft position sensor: Removal Refitting**) (MR 392, 13B, Diesel injection).
- ☐ Disconnect the coolant temperature sensor.
- □ Remove the injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection).



- ☐ Remove the wiring channel bolts (17) on the body.
- □ Remove:
  - the computer supporting bracket,
  - the wiring channel.
- ☐ Fit a hose clamp between the brake fluid reservoir and clutch master cylinder.




☐ Disconnect the connector (18) from the reversing sensor.

#### **WARNING**

Do not pull on the clip, any incorrect handling of the clip will mean that the clutch control pipes will have to be replaced.

- □ Disconnect the clutch slave cylinder by pressing on the clip (19).
- ☐ It is essential to place protective plugs in the ends of the hoses.
- ☐ Unclip the breather pipe from the gearbox on the engine.




118429

- ☐ Fit:
  - the (Mot. 1453),


K9K, and TL4

- -the safety strap(s).
- ☐ Remove the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting).

### **II - OPERATION FOR REMOVAL OF PART CONCERNED**



116340




- ☐ Remove:
  - the gearbox nuts (23),
  - the gearbox bolts (24),


- the gearbox studs (25).

## Manual gearbox: Removal - Refitting

K9K, and TL4



116711



116713

- ☐ Fit the (Bvi. 1718) on a component jack.
- Fit:
  - the **(Bvi. 1718)** and the **component jack** under the gearbox,
  - the bracket (26) using the nuts (27),
  - -the support (28),
  - the pin (29),
  - the rod (30) using the bracket (31) and the bolt (32)
- ☐ Tighten the rod (30) anti-clockwise in order to avoid

tilting the gearbox.

☐ Remove the gearbox using the (Bvi. 1718).

### REFITTING

### I - REFITTING PREPARATION OPERATION

L

### **WARNING**

To avoid damaging the clutch slave cylinder, do not coat the gearbox output shaft with grease.

### **WARNING**


Do not grease the clutch shaft splines.

### **WARNING**

To prevent leaks, replace the slave cylinder after replacing the clutch pressure plate.

### **WARNING**

It is essential to replace the differential output lip seal each time the driveshafts are removed.



☐ Remove:


- the clutch hydraulic slave cylinder bolts (33),
- the clutch hydraulic slave cylinder (34) .
- ☐ Check that the engine-gearbox centering ringsare in place and correctly positioned.

## Manual gearbox: Removal - Refitting

### K9K, and TL4

- ☐ Pre-fill the hydraulic slave cylinder using a syringe.
- Position the new clutch hydraulic slave cylinder.
- ☐ Refit the bolts for the clutch hydraulic slave cylinder.
- □ Replace the left and right-hand differential seals (see 21A, Manual gearbox, Differential output seal: Removal Refitting, page 21A-46).

### Replacing the gearbox



116712

#### Note


To fit the tool on the new gearbox, follow the same steps as for the removal operation.

☐ Fit the new gearbox on the (Bvi. 1718).

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the gearbox using the (Bvi. 1718).
- Refit the gearbox studs.
- ☐ Fit without tightening:
  - the gearbox bolts,
  - the nuts on the studs.
- ☐ Remove the (Bvi. 1718).
- ☐ Tighten to torque:
  - -the nuts on the studs (44 Nm),
  - the gearbox bolts (44 Nm).

### **III - FINAL OPERATION.**



12808

### Note:

If equipped with the 5<sup>th</sup>injector.

After carrying out the operation, check that the dimension between the driveshaft and the hose for the 5<sup>th</sup>injector is at least 25mm.

To avoid damaging the hose.

#### □ Connect:

- the hydraulic slave cylinder,
- the reverse gear connector.
- ☐ Remove the hose clamp.
- □ Bleed the hydraulic clutch control (see Clutch circuit: Bleed) (MR 392, 37A, Mechanical component controls).

### ☐ Refit:

- the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting),
- the (Mot. 1453),
- the safety strap(s).
- ☐ Clip the breather pipe from the gearbox on the engine.
- ☐ Fit:
  - the computer supporting bracket,

### K9K, and TL4

- the wiring harness channel on the body.

### ☐ Refit:

- the wiring channel bolts on the body,
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- ☐ Connect the coolant temperature sensor.

#### □ Refit:

- -the engine speed and position sensor (see **Crankshaft position sensor: Removal Refitting**) (MR 392, 13B, Diesel injection).
- the starter (see **Starter: Removal Refitting**) (MR 392, 16A, Starting Charging),
- the wiring harness channel mounting on the gearbox.

### ☐ Clip:


- -the expansion bottle (see **Expansion bottle: Removal Refitting**) (MR 392, 19A, Cooling).
- the gearbox control cable sleeve stops on the gearbox.
- the control cables onto the gearbox.

### K9K, and 772

- ☐ Fit the diesel injector wiring harness strut.
- ☐ the diesel injector wiring harness strut bolt.
- ☐ Connect the diesel injector connector.
- ☐ Fit the exhaust strut.
- ☐ Fit without tightening the exhaust strut bolts and nut.
- ☐ Tighten to torque:
  - the exhaust strut bolt on the gearbox (21 Nm),
  - -the exhaust strut nut on the gearbox (21 Nm),
  - the exhaust strut bolt on the catalytic converter (21 Nm).

#### □ Refit:

- the tie rod,
- the front axle subframe front left-hand bolt,
- the tie-rod bolt,
- the side stiffener,
- the side stiffener bolts,
- ☐ Tighten to torque:
  - the front axle subframe front left-hand bolt (105 Nm).
  - the tie-rod bolt (21 Nm),
  - the side stiffener bolts (21 Nm).



123524

### Note:

Refit the earth terminal, aligning the indelible marks on the gearbox casing.

When reassembling, improper positioning of the earth terminal on the gearbox casing could result in damage to the earth terminal or earth wiring.

- ☐ The earth wiring must be refit as shown in the illustration.
- ☐ Refit the earth wiring bolt (35) to the manual gearbox.
- ☐ Tighten the earth wiring bolt (35) on the manual gearbox.

K9K, and TL4

#### □ Refit:

- -the front axle subframe (see Front axle subframe: Removal - Refitting) (MR 392, 31A, Front axle components).
- the rear suspended engine mounting (see **Lower engine tie-bar: Removal Refitting**) (MR 392, 19D, Engine mounting).,
- the radiator mounting cross member (see **Radiator** mounting cross member: Removal Refitting) (MR 393, 41A, Front lower structure).
- ☐ Detach the « cooling radiator fan unit » assembly from the upper cross member.

### K9K, and 772

- ☐ Position the heating element and electric coolant pump mounting on the radiator mounting cross member.
- □ Refit:
  - -the bolt from the heating element and coolant pump support on the radiator mounting cross member.
  - the earth wiring bolt,
- ☐ Connect the connector to the heating element unit.

### ☐ Refit:

- -the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9),
- -the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2).
- ☐ Top up the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).

### ☐ Refit:

- -the front bumper (see **Front bumper: Removal - Refitting**) (MR 393, 55A, Exterior protection),
- the engine undertray,
- the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture).

- the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
- the battery (see Battery: Removal Refitting)
   (MR 392, 80A, Battery),
- the scoop under the scuttle panel grille (see Scoop under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment).

21A

F4R, and 830, and TL4

Special tooling required				
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.			
Bvi. 1718	Component support plate for removal - refitting of gearboxes.			


# Equipment required component jack

Tightening torques ▽	
gearbox bell housing mounting bolts	44 Nm
gearbox bell housing mounting nuts	44 Nm
starter mounting bolts	40 Nm

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION


- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Use the lifting eye on the gearbox side and its mounting bolts (see **Lifting eyes: Removal Refitting**) (MR 392, 11A, Top and front of engine).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- ☐ Unclip the breather pipe from the gearbox.
- □ Remove:
  - -the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
  - the battery tray bracket (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
  - the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection),
- ☐ Drain the gearbox (see ).
- □ Remove the left-hand and right-hand driveshafts (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9).



☐ Strap the cooling unit in place.

### □ Remove:

- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure).
- the front axle sub-frame (see Front axle sub-frame: Removal Refitting) (MR 392, 31A, Front axle components).




116440


☐ Remove the earth strap mounting bolt (1).



F4R, and 830, and TL4



☐ Unclip the gearbox controls (2).




- □ Disconnect:
  - the connector (3) from the reverse gear switch,
  - -the pipe (4) from the clutch slave cylinder by pushing on the clip (5).
- ☐ Fit the lifting eye on the gearbox side (see **Lifting** eyes: Removal Refitting) (MR 392, 11A, Top and front of engine).
- ☐ Remove the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment).


☐ Fit the (Mot. 1453).

# II - OPERATION FOR REMOVAL OF PART CONCERNED

□ Remove the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting).

F4R, and 830, and TL4







- □ Remove:
  - the starter mounting bolts,
  - the gearbox bell housing mounting nuts,
  - -the gearbox bell housing mounting bolts, leaving one mounting bolt in place,
  - the gearbox mounting studs.
- ☐ Fit the (Bvi. 1718) on a component jack.

### Manual gearbox: Removal - Refitting



F4R, and 830, and TL4





### ☐ Fit:

- the **(Bvi. 1718)** and the **component jack** under the gearbox,
- the bracket (6) using mounting nuts (7),
- -the support (8),
- the pin (9),
- -the rod (10) using the bracket (11) and the mounting bolt (12).
- ☐ Tighten the rod (10) in an anti-clockwise direction to prevent the gearbox from tilting.

#### □ Remove:

- the remaining gearbox bell housing mounting bolt,
- the gearbox using the (Bvi. 1718).

### REFITTING

#### I - REFITTING PREPARATIONS OPERATION

Do not grease the clutch shaft splines.

#### **WARNING**

**WARNING** 

To prevent leaks, replace the slave cylinder after replacing the clutch pressure plate.

### **WARNING**

It is essential to replace the differential output lip seal each time the driveshafts are removed.

- □ Replace the left-hand and right-hand differential output seals (see 21A, Manual gearbox, Differential output seal: Removal Refitting, page 21A-46).
- ☐ Refit the gearbox mounting studs.
- ☐ Check the condition of the centring devices on the gearbox.

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Position the gearbox using the (Bvi. 1718).
- ☐ Refit one gearbox bell housing mounting bolt.
- ☐ Remove the (Bvi. 1718) from the gearbox.
- □ Refit:
  - the gearbox bell housing mounting bolts,
  - the gearbox bell housing mounting nuts,
  - the starter mounting bolts.
- ☐ Torque tighten:
  - the gearbox bell housing mounting bolts (44 Nm),
  - the gearbox bell housing mounting nuts (44 Nm),
  - the starter mounting bolts (40 Nm).
- □ Refit the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting).

21A

F4R, and 830, and TL4 □ Remove: -the (Mot. 1453), -the lifting eye on the gearbox side (see Lifting eyes: Removal - Refitting) (MR 392, 11A, Top and front of engine). ☐ Connect the clutch slave cylinder pipe. ☐ Refit the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment). ☐ Bleed the hydraulic clutch system (see Clutch circuit: Bleed) (MR 392, 37A, Mechanical component controls). ☐ Connect the reverse gear switch connector. ☐ Clip the gear controls into place. ☐ Refit the earth strap and its mounting bolt. **III - FINAL OPERATION.** □ Refit: -the front axle sub-frame (see Front axle subframe: Removal - Refitting) (MR 392, 31A, Front axle components). - the radiator mounting cross member (see **Radiator** mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure). ☐ Remove the retaining belt from the cooling unit. □ Refit: -the front bumper (see Front bumper: Removal -Refitting) (MR 393, 55A, Exterior protection), - the left-hand and right-hand driveshafts (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9), - the front wheels (see Wheel: Removal - Refitting) (MR 392, 35A, Wheels and tyres), - the battery tray bracket (see Battery tray: Removal - Refitting) (MR 392, 80A, Battery), - the air filter unit (see Air filter unit: Removal - Refitting) (MR 392, 12A, Fuel mixture). ☐ Clip the breather pipe onto the gearbox.  $\Box$  Fill the gearbox (see ) . ☐ Connect the battery (see Battery: Removal - Refit-

ting) (MR 392, 80A, Battery).



M4R, and TL4

Special tooling required				
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.			
Bvi. 1718	Component support plate for removal - refitting of gear-boxes.			


Equipment required			
safety strap(s)			
component jack			

	1	ightening torques ▽	
gearbox bolts	bell	housing	44 Nm
gearbox nuts	bell	housing	44 Nm

### REMOVAL

### I - REMOVAL PREPARATION OPERATION


- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- ☐ Remove the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove:
  - the battery tray bracket (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
  - the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - the front section of the front wheel arch liners (see Front wheel arch liner: Removal Refitting) (MR 393, 55A, Exterior protection).
  - -the front bumper (see Front bumper: Removal Refitting) (MR 393, 55A, Exterior protection),
- $\ \ \square$  Drain the gearbox (see ) .
- □ Remove the left-hand and right-hand driveshafts (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9) and (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2).



□ Attach the cooling assembly using a safety strap(s).


### □ Remove:

- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure).
- the front axle sub-frame (see Front axle sub-frame: Removal Refitting) (MR 392, 31A, Front axle components).





☐ Remove the earth wiring bolt (1).

M4R, and TL4



- $\ \ \Box$  Unclip the gearbox controls (2) .
- ☐ Remove the wiring harness channel bolts.





### ☐ Disconnect:


- the connector (3) from the reverse gear switch,
- the downstream oxygen sensor connector,
- the clutch control pipes (4) by pushing on the clip (5) .

### □ Remove:


 the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment).

M4R, and TL4

- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment).



☐ Disconnect the union (6) from the brake servo pipe on the vacuum pump.




☐ Position the (Mot. 1453) (7).


### **WARNING**

Do not deform the air conditioning pipes.

# II - OPERATION FOR REMOVAL OF PART CONCERNED

□ Remove the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting).







### □ Remove:

- the starter bolts (see Starter: Removal Refitting)
   (MR 392, 16A, Starting Charging),
- the gearbox nuts,
- the gearbox bolts, leaving one bolt in place,
- the gearbox studs.
- ☐ Unclip the breather pipe from the gearbox.
- ☐ Fit the (Bvi. 1718) on a component jack.

M4R, and TL4



- ☐ Fit:
  - the **(Bvi. 1718)** and the **component jack** under the gearbox,
  - the bracket (8) using the nuts (9),



- ☐ Tap the hole (14) using a self-tapping bolt (Part no.: 77 03 002 244) to attach the gearbox to the support using the rod (12).
- ☐ Fit:
  - the shim (10),
  - the shim (11),
  - the rod (12) using the bracket (13) and the bolt (14)
- ☐ Tighten the rod (12) in an anti-clockwise direction to prevent the gearbox from tilting.

### Manual gearbox: Removal - Refitting



M4R, and TL4



### Note:

Check that the pulleys on the accessories side are not pressing against the side member on the right-hand side of the vehicle when the engine and transmission assembly is being lowered.

### □ Remove:

- -the gearbox bolt,
- the gearbox using the (Bvi. 1718).

### **REFITTING**

### I - REFITTING PREPARATIONS OPERATION

### **WARNING**

Do not grease the clutch shaft splines.

### WARNING

To prevent leaks, replace the slave cylinder after replacing the clutch pressure plate.

### **WARNING**

It is essential to replace the differential output lip seal each time the driveshafts are removed.


□ Replace the left-hand and right-hand differential our put seals (see 21A, Manual gearbox, Differential output seal: Removal - Refitting, page 21A-46).
☐ Refit the gearbox studs.
Check the condition of the centring devices on th gearbox.
II - REFITTING OPERATION FOR PART CONCERNED
☐ Position the gearbox using the (Bvi. 1718).
☐ Refit a gearbox bell housing bolt,
☐ Remove the (Bvi. 1718) from the gearbox.
☐ Refit:
- the gearbox bell housing bolts,
- the gearbox bell housing nuts,
<ul> <li>the starter bolts (see Starter: Removal - Refitting (MR 392, 16A, Starting - Charging),</li> </ul>
☐ Torque tighten:
- the gearbox bell housing bolts (44 Nm),
- the gearbox bell housing nuts (44 Nm),
☐ Refit the left-hand suspended engine mounting (se Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting).
☐ Remove the <b>(Mot. 1453)</b> .
☐ Refit the hose connected to the brake servo.
☐ Connect the clutch slave cylinder pipe.
☐ Refit:
- the scoop under the scuttle panel grille (see Scoo under the scuttle panel grille: Removal - Refin ting) (MR 393, 56A, Exterior equipment).
<ul> <li>the scuttle panel grille (see Scuttle panel grille Removal - Refitting) (MR 393, 56A, Exterio equipment).</li> </ul>
☐ Bleed the hydraulic clutch system (see Clutch circuit: Bleed) (MR 392, 37A, Mechanical componer controls).
☐ Connect the reverse gear switch connector.
☐ Clip the gear controls into place.
□ Refit:
- the wiring harness channel bolt,
- the earth wiring fitted with its bolt.

☐ Reposition the downstream oxygen sensor connec-

tor.

21A

M4R, and TL4



☐ Refit the battery (see **Battery: Removal - Refitting**)

(MR 392, 80A, Battery).

## Manual gearbox: Removal - Refitting



K4M, and TL4

Special tooling required					
Ms. 583	<b>Ms. 583</b> Pipe clamps.				
Bvi. 1718	Component support plate for removal - refitting of gear-boxes.				

Equipment required
indelible pencil
component jack

Tightening torques ♡			
gearbox nuts	44 N.m		
gearbox bolts	44 N.m		
front left-hand bolt of the front axle sub-frame	105 N.m		
earth wiring bolt on the gearbox	24 N.m		

### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- □ Remove:
  - the engine undertray bolts,
  - the engine undertray,
  - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
  - the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
  - the front bumper (see Front bumper: Removal Refitting) (55A, Exterior protection),
  - -the windscreen wiper arms (see Windscreen wiper arm: Removal Refitting) (85A, Wiping Washing),
  - -the scuttle panel grille (see **Scuttle panel grille**: **Removal Refitting**) (56A, Exterior equipment),
  - -the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (56A, Exterior equipment).
- ☐ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).

#### □ Remove:

- the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9)
- the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
- the differential output seals (see 21A, Manual gearbox, Differential output seal: Removal - Refitting, page 21A-46),
- the air resonator (see Air resonator: Removal -Refitting) (12A, Fuel mixture),
- the battery (see ) (80A, Battery),
- the battery tray (see Battery tray: Removal Refitting) (80A, Battery),
- the air filter unit (see Air filter unit: Removal Refitting) (12A, Fuel mixture),
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (41A, Front lower structure),
- the starter (see Starter: Removal Refitting)
   (16A, Starting Charging),
- the lower engine tie-bar (see Lower engine tiebar: Removal - Refitting) (19D, Engine mounting),
- the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (19D, Engine mounting).




K4M, and TL4



- ☐ Unclip:
  - -the gear control cables (1) from the selector ball joints using an open-jawed spanner,
  - the gear control cables (2) from their support.
- ☐ Fit the tool (Ms. 583) between the brake fluid reservoir and the clutch master cylinder.


### WARNING

Do not pull the clip. If it is incorrectly handled in any way, the pipe will need to be replaced.



- □ Disconnect:
  - the hydraulic clutch control pipe by pressing on the clip (3) ,
  - the connector (4) from the reverse gear switch,
- ☐ Insert the blanking plugs.

K4M, and TL4




Note:


Before removing the earth terminal, mark its position using a **indelible pencil** by drawing a line on the earth terminal and on the gearbox casing.

When reassembling, improper positioning of the earth terminal on the gearbox casing could result in damage to the earth terminal or earth wiring.

☐ Remove the earth wiring bolt (5).



- ☐ Remove the bolt (6) from the wiring harness channel on the gearbox.
- ☐ Disconnect the breather pipe (7) from the gearbox.
- ☐ Remove the crankshaft position sensor (see Crankshaft position sensor: Removal Refitting).




141469


- □ Loosen the front left-hand bolt (8) on the front axle subframe.
- ☐ Pivot the tie rod at (9).

K4M, and TL4


### **II - OPERATION FOR REMOVAL OF PART** CONCERNED








☐ Remove the bolts (10) from the gearbox.





- ☐ Fit the (Bvi. 1718) on a component jack.
- ☐ Position the tool (Bvi. 1718) and the component jack under the gearbox.
- ☐ Tighten the rod (11) anti-clockwise in order to avoid tilting the gearbox.
- ☐ Remove:
  - the gearbox nuts,
  - the gearbox using the tool (Bvi. 1718),
  - the clutch thrust bearing (see 20A, Clutch, Clutch thrust bearing: Removal - Refitting, page 20A-**11**).

Manual gearbox: Removal - Refitting

ĮK.	4M, and TL4		
REFITTING			☐ Connect
			☐ Remove
I - REFITTING PREPARATION OPERATION			☐ Clip:
□ parts always to be replaced: Clutch thrust bearing.			- the gea
			- the gea joints.
	WARNING		☐ Refit:
	To avoid damaging the slave cylinder, do not coat the gearbox output shaft with grease.		- the left Left-ha
			moval -

### WARNING

Do not grease the clutch shaft splines.

☐ Check that the centring dowelsare in place.

### **II - REFITTING OPERATION FOR PART CONCERNED**

- □ Refit: -a new clutch thrust bearing (see 20A, Clutch, Clutch thrust bearing: Removal - Refitting, page 20A-11), - the gearbox using the (Bvi. 1718).
- ☐ Remove the tool (Bvi. 1718).
- ☐ Tighten to torque:
  - the gearbox nuts (44 N.m),
  - the gearbox bolts (44 N.m).
- **III FINAL OPERATION** ☐ Fit the tie-rod. ☐ Refit the front left-hand bolt on the front axle subframe. ☐ Torque tighten the front left-hand bolt of the front axle sub-frame (105 N.m). ☐ Refit the crankshaft position sensor (see Crankshaft position sensor: Removal - Refitting) . ☐ Connect the gearbox breather pipe. ☐ Refit the wiring channel bolt on the gearbox. ☐ Refit the earth cable respecting the marks made during removal. ☐ Refit the earth wiring bolt on the gearbox. ☐ Torque tighten the earth wiring bolt on the gearbox (24 N.m).

☐ Connect the reverse gear switch connector.

Remove the blanking plugs.

- the clutch slave cylinder.
- the tool (Ms. 583).
  - ir control cables onto their support,
  - ar control cables onto the gear selector ball
  - -hand suspended engine mounting (see and suspended engine mounting: Re-Refitting) (19D, Engine mounting),
  - the lower engine tie-bar (see Lower engine tiebar: Removal - Refitting) (19D, Engine mounting),
  - the starter (see Starter: Removal Refitting) (16A, Starting - Charging),
  - the radiator mounting cross member (see **Radiator** mounting cross member: Removal - Refitting) (41A, Front lower structure),
  - the air filter unit (see Air filter unit: Removal Refitting) (12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (80A, Battery),
  - the battery (see ) (80A, Battery),
  - the air resonator (see Air resonator: Removal -Refitting) (12A, Fuel mixture),
  - the differential output seals (see 21A, Manual gearbox, Differential output seal: Removal - Refitting, page 21A-46),
  - the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
  - the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9),
  - the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal - Refitting) (56A, Exterior equipment),
  - the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (56A, Exterior equipment),
  - the windscreen wiper arms (see Windscreen wiper arm: Removal - Refitting) (85A, Wiping -Washing),
  - the front bumper (see Front bumper: Removal -Refitting) (55A, Exterior protection),
  - the front wheel arch liners (see Front wheel arch liner: Removal - Refitting) (55A, Exterior protection),

### K4M, and TL4

- the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres).
- ☐ Perform the following operations:
  - fill the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3),
  - -bleed the clutch hydraulic clutch (see **Clutch circuit: Bleed**) (37A, Mechanical component controls).
- ☐ Refit the engine undertray.

# MANUAL GEARBOX Input shaft lip seal: Removal - Refitting



JH3 or JR5

□ Replace the lip seal after opening the gearbox (see Technical Note 3661A, gearbox JH - JR).

### Input shaft lip seal: Removal - Refitting



TL4

Special tooling required			
Bvi. 1601	Tool for fitting the primary shaft seal.		

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION


- □ Remove:
  - -the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal Refitting, page 21A-12),
  - the clutch thrust bearing (see 20A, Clutch, Clutch thrust bearing: Removal - Refitting, page 20A-11).

## II - OPERATION FOR REMOVAL OF PART CONCERNED

☐ Drill a hole in the seal, using a **2.5 mm** drill bit.

### WARNING

Do not scratch the shaft or mating face.




20714

- ☐ Fit a bolt in seal (1).
- ☐ Extract the seal (1) using pliers.

### REFITTING

## I - REFITTING OPERATION FOR PART CONCERNED



- ☐ Fit a new seal with its protector using the (Bvi. 1601).
- ☐ Remove the protector.

### **II - FINAL OPERATION**

- □ Refit:
  - the clutch thrust bearing (see 20A, Clutch, Clutch thrust bearing: Removal - Refitting, page 20A-11).
  - the gearbox (see 21A, Manual gearbox, Manual gearbox: Removal Refitting, page 21A-12).

## Differential output seal: Removal - Refitting



JH3 or JR5


Special tooling required				
Bvi. 1666	Tool seals		fitting	differential

### REMOVAL

### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- □ Remove:
  - -the front wheel from the side in question (see Wheel: Removal - Refitting) (MR 392, 35A, Wheels and tyres),
  - the front brake pads from the side in question (see Front brake pads: Removal - Refitting) (MR 392, 31A, Front axle components),
  - the engine undertray mounting bolts,
  - the engine undertray.
- ☐ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining - Filling, page 21A-3).
- ☐ Remove the driveshaft from the side in question (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2)

### **II - OPERATION FOR REMOVAL OF PART** CONCERNED



109147

- ☐ Tap the base of the lip seal using a pin punch and a small hammer to release it and cause it to turn in its housing.
- ☐ Withdraw the lip seal using a large screwdriver, taking care not to damage the differential housing.


### Differential output seal: Removal - Refitting

21A

JH3 or JR5

### **REFITTING**

## I - REFITTING OPERATION FOR PART CONCERNED



- 109407
- □ Refit the seal using the (Bvi. 1666) (C), suffix A on the right-hand side, and suffix B on the left-hand side.
- ☐ Strike the (Bvi. 1666) (C) with a copper hammer (D) to fully seat the differential output seal

### **II - FINAL OPERATION.**

- ☐ Position the driveshaft in relation to the sunwheel.
- ☐ Refit the driveshaft on the side in question (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting, page 29A-2) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting, page 29A-2)
- ☐ Fill the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- ☐ Refit:
  - the engine undertray,
  - the engine undertray mounting bolts,
  - the front brake pads from the side in question (see **Front brake pads: Removal Refitting**) (MR 392, 31A, Front axle components),
  - the front wheel on the side in question (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),

□ Connect the battery (see **Battery**: **Removal - Refitting**) (MR 392, 80A, Battery).

# Differential output seal: Removal - Refitting



TL4

Special tooling required		
Bvi. 1854	Differential output seal fitting tool TL4	

### **Equipment required**

roll pin punch

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (02A, Lifting equipment).
- □ Remove:
  - the engine undertray bolts,
  - the engine undertray.
- ☐ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining - Filling, page 21A-3).

### 1 - When replacing the differential output seal on the left-hand side

- □ Remove:
  - -the front left-hand wheel (see Wheel: Removal -Refitting) (35A, Wheels and tyres),
  - -the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2).

### 2 - When replacing the differential output seal on the right-hand side


- Remove:
  - the front right-hand wheel (see Wheel: Removal -Refitting) (35A, Wheels and tyres),
  - -the front right-hand wheel driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9).

### II - REMOVAL OPERATION FOR THE **DIFFERENTIAL OUTPUT SEAL**

Left-hand differential output seal



### Right-hand differential output seal



- ☐ Tap the base of the lip seal using a roll pin punch and a small hammer to release it and make it turn in its housing.
- ☐ Remove the lip seal using a large screwdriver, taking care not to damage the differential housing.

# MANUAL GEARBOX Differential output seal: Removal - Refitting

21A

TL4

### **REFITTING**


- I REFITTING PREPARATION OPERATION
- □ parts always to be replaced: Differential output seal.

## Differential output seal: Removal - Refitting




TL4

## II - REFITTING OPERATION FOR THE DIFFERENTIAL OUTPUT SEAL




Refitting the right-hand side differential output seal



125895

### Refitting the left-hand side differential output seal.



- ☐ The new differential output seal is refitted using the tool (Bvi. 1854) (1) consisting of:
  - a mandrel (2) for the right-hand side,
  - a mandrel (3) for the left-hand side.
- ☐ Oil the internal surface of the new differential output seal.
- ☐ Fit:
  - the new differential output seal on the gearbox,
  - the mandrel (2) or (3) of the tool (Bvi. 1854) on the new differential output seal.
- ☐ Tap the tool (1) with a copper hammer to fit the new differential output seal fully.

### **III - FINAL OPERATION**

### 1 - Refitting the left-hand driveshaft

### □ Refit:

- the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
- the front left-hand wheel (see **Wheel: Removal Refitting**) (35A, Wheels and tyres).

### 2 - Refitting the right-hand driveshaft

### ☐ Refit:

 the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9) ,

# MANUAL GEARBOX Differential output seal: Removal - Refitting

**21A** 

TL4

-the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

### 3 - Final operation

- ☐ Fill the gearbox and check the level (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- ☐ Refit the engine undertray.

## Reverse gear switch: Removal - Refitting



TL4

Special tooling required	
Bvi. 1934	Socket for removing/refitting reverse gear switch


### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

### □ Remove:


- -the battery (see **Battery: Removal Refitting**) (80A, Battery),
- -the battery tray (see **Battery tray: Removal Refitting**) (80A, Battery).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



125695

☐ Disconnect the connector (1) from the reverse gear switch.



□ Remove the reverse gear switch using the socket for removing/refitting the reverse gear switch (Bvi. 1934) (2).

### **REFITTING**

## I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the reverse gear switch.
- ☐ Tighten the reverse gear switch using the socket for removing/refitting the reverse gear switch (Bvi. 1934).
- ☐ Connect the reverse gear switch connector.

### **II - FINAL OPERATION**

- ☐ Refit:
  - the battery tray (see Battery tray: Removal Refitting) (80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (80A, Battery).

### Reverse gear switch: Removal - Refitting



JH3 or JR5

Special tooling required		
Bvi. 1934	Socket for removing/refitting reverse gear switch	

Tightening torques	
reverse gear switch	23 N.m

### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle**: **Towing and lifting**) (02A, Lifting equipment).
- ☐ Remove the engine undertray.

# II - OPERATION FOR REMOVAL OF PART CONCERNED



12557

Disconnect the connector (1) from the reverse gear switch.



☐ Remove the reverse gear switch (2) using the (Bvi. 1934).

### Note:

Seal the housing of the reverse gear switch while replacing the part.

### **REFITTING**

## I - REFITTING OPERATION FOR PART CONCERNED

- □ Apply some SILICONE ADHESIVE SEALANT (see Vehicle: Parts and consumables for the repair) (04B, Consumables - Products) to the threading of the reverse gear switch.
- ☐ Refit the reverse gear switch using the (Bvi. 1934).
- ☐ Torque tighten the reverse gear switch (23 N.m).
- ☐ Connect the reverse gear switch connector.

### **II - FINAL OPERATION**

- ☐ Fill the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- ☐ Refit the engine undertray.

# SEQUENTIAL GEARBOX Sequential gearbox: Precautions for the repair



D4F or K9K, and JA3 or JA5

### **Equipment required**

Diagnostic tool

### I - SEQUENTIAL GEARBOX

### **WARNING**

If any operation is carried out on the electro-hydraulic unit, it is essential to clean the unit using a cleaning product and compressed air.

Never leave the circuit open and never use a high pressure cleaner.

### **II - SEQUENTIAL GEARBOX COMPUTER**

To disconnect the computer, switch off the ignition and wait for **1 minute**.

### **III - ELECTRO-HYDRAULIC UNIT**

Discharge the pressure accumulator using the **Diagnostic tool** before any operation on the electro-hydraulic unit.

## SEQUENTIAL GEARBOX

### Pressure accumulator: Removal - Refitting



K9K, and JA5

Special tooling required	
Mot. 445	Oil filter strap wrench.

### **Equipment required**

Diagnostic tool

Tightening torques ▽	
lifting eye nut on the gearbox	21 Nm

### REMOVAL

### I - REMOVAL PREPARATION OPERATION

### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.


To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

#### □ Remove:


- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).



### □ Remove:

- the lifting eye nut on the gearbox (1),
- the lifting eye on the gearbox (2).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



☐ Remove the pressure accumulator (3) using the (Mot. 445).

### **SEQUENTIAL GEARBOX**

Pressure accumulator: Removal - Refitting

21B

K9K, and JA5

### **REFITTING**

### I - REFITTING OPERATION FOR PART **CONCERNED** ☐ Fit the pressure accumulator. ☐ Tighten the pressure accumulator using the (Mot. 445). ☐ Affix the safety label to the pressure accumulator. □ Refit: - the lifting eye on the gearbox, - the lifting eye nut on the gearbox. ☐ Tighten to torque the lifting eye nut on the gearbox (21 Nm). ☐ Refit: - the air filter unit (see Air filter unit: Removal - Refitting) (MR 392, 12A, Fuel mixture). - the battery tray (see Battery tray: Removal - Refitting) (MR 392, 80A, Battery), -the battery (see Battery: Removal - Refitting) (MR 392, 80A, Battery), II - FINAL OPERATION. ☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394, 21B, Sequential gearbox). **WARNING** After the accumulator has been fully filled (15 seconds after the ignition has been switched on):

the oil is at the MIN mark.

## SEQUENTIAL GEARBOX

### Pressure accumulator: Removal - Refitting



D4F, and JA3

Special tooling required	
Mot. 445	Oil filter strap wrench.

### **Equipment required**

Diagnostic tool

Tightening torques ▽	
lifting eye nut on the gearbox	21 Nm

### REMOVAL

### I - REMOVAL PREPARATION OPERATION

### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.


To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

#### □ Remove:


- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).



#### □ Remove:

- the lifting eye nut on the gearbox (1),
- the lifting eye on the gearbox (2).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



114159

☐ Remove the pressure accumulator (3) using the (Mot. 445).

Pressure accumulator: Removal - Refitting

21B

D4F, and JA3

#### **REFITTING**

### I - REFITTING OPERATION FOR PART **CONCERNED** ☐ Fit the pressure accumulator. ☐ Tighten the pressure accumulator using the (Mot. 445). ☐ Affix the safety label to the pressure accumulator. □ Refit: - the lifting eye on the gearbox, - the lifting eye nut on the gearbox. ☐ Tighten to torque the lifting eye nut on the gearbox (21 Nm). ☐ Refit: - the air filter unit (see Air filter unit: Removal - Refitting) (MR 392, 12A, Fuel mixture), - the battery tray (see Battery tray: Removal - Refitting) (MR 392, 80A, Battery), -the battery (see Battery: Removal - Refitting) (MR 392, 80A, Battery). II - FINAL OPERATION.

## WARNING

21B, Sequential gearbox).

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394,

### Pump assembly reservoir: Removal - Refitting



K9K, and JA5

Equ	ipment required
Diagnostic tool	

pump assembly reservoir bolts

10 Nm

#### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the Diagnostic tool.

To discharge the accumulator, run command « Discharge pressure accumulator » AC081.


To confirm the pressure drop, read the « Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Remove the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).

#### **II - OPERATION FOR REMOVAL OF PART** CONCERNED



18012

- Remove:
  - the bolts (1) from the pump assembly reservoir,
  - the reservoir (2) from the pump assembly.

#### REFITTING

#### I - REFITTING OPERATION FOR PART **CONCERNED**

- □ Refit:
  - the pump assembly reservoir,
  - the pump assembly reservoir bolts.
- ☐ Torque tighten the pump assembly reservoir bolts (10 Nm).

#### II - FINAL OPERATION.

☐ Refit the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).

### Pump assembly reservoir: Removal - Refitting



D4F, and JA3

## Equipment required

Diagnostic tool

#### 

pump assembly reservoir bolts

10 Nm

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic tool**.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.


To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Remove the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal Refitting, page 21B-12).

### II - OPERATION FOR REMOVAL OF PART CONCERNED



18012

- □ Remove:
  - the bolts (1) from the pump assembly reservoir,
  - the reservoir (2) from the pump assembly.

#### **REFITTING**

### I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the pump assembly reservoir,
  - the pump assembly reservoir bolts.
- ☐ Torque tighten the pump assembly reservoir bolts (10 Nm).

#### II - FINAL OPERATION.

□ Refit the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).

## SEQUENTIAL GEARBOX Electro-hydraulic unit: Removal - Refitting



K9K, and JA5

#### **Equipment required**

Diagnostic tool

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

Note:

When replacing the electric pump assembly, always replace the control relay.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).

### SEQUENTIAL GEARBOX Electro-hydraulic unit: Removal - Refitting

K9K, and JA5



#### Note:

The electro-hydraulic unit includes the pump assembly and the actuator module.

#### □ Remove:

- -the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12),
- -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).

#### **II - OPERATION FOR REMOVAL OF PART CONCERNED**

☐ Remove the electro-hydraulic unit.

#### REFITTING

#### I - REFITTING OPERATION FOR PART **CONCERNED**

#### ☐ Refit:

- the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34),
- the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).

#### **II - FINAL OPERATION**

☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394, 21B, Sequential gearbox).

#### **WARNING**

## SEQUENTIAL GEARBOX Electro-hydraulic unit: Removal - Refitting



D4F, and JA3

#### **Equipment required**

Diagnostic tool

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

Note:

When replacing the electric pump assembly, always replace the control relay.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).

### Electro-hydraulic unit: Removal - Refitting

D4F, and JA3



114644

#### Note:

The electro-hydraulic unit includes the pump assembly and the actuator module.

#### □ Remove:

- -the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12),
- -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).

#### **II - OPERATION FOR REMOVAL OF PART CONCERNED**

☐ Remove the electro-hydraulic unit.

#### REFITTING

#### I - REFITTING OPERATION FOR PART **CONCERNED**

#### ☐ Refit:

- the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34),
- the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).

#### **II - FINAL OPERATION**

☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394, 21B, Sequential gearbox).

#### **WARNING**

21B

K9K, and JA5

Special tooling required	
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.

Equipment required
Diagnostic tool
safety strap(s)

Tightening torques ♡	
rigiliening tolques 🤍	
pump assembly lower bolts	24 N.m
pump assembly upper bolt	24 N.m
low pressure pump pipe	14 N.m
high pressure pump pipe	14 N.m

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

#### Note:

When replacing the electric pump assembly, always replace the control relay.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).


#### □ Remove:

- the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery),
- the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
- the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the scoop under the scuttle panel grille (see Scoop under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.




- 112211
- □ Remove the Protection and Switching Unit bolts (1).
- ☐ Remove:
  - the Protection and Switching Unit,
  - the wiring harness under the injection computer.

K9K, and JA5




- ☐ Fit the (Mot. 1453) with a safety strap(s).
- □ Remove:
  - -the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
  - the side stiffener bolts on the left-hand side of the vehicle.
  - the side stiffener on the left-hand side of the vehicle,
  - the engine undertray,
  - -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (MR 392, 19D, Engine mounting).



#### □ Disconnect:

- the connector (2) from the actuator module,
- the connector (3) from the pump assembly.


K9K, and JA5




114644

- ☐ Remove:
  - -the clutch pipe (4),
  - the clutch pipe bracket (5).
- ☐ Cut the clip on the clutch pipe (6).


K9K, and JA5






☐ Remove the high pressure pump pipe (7) and (8).

K9K, and JA5



114644


☐ Remove the low pressure pump pipe (9).



□ Disconnect the clutch control pipe (10) on the hydraulic cylinder by pushing on the clip.

K9K, and JA5

## II - OPERATION FOR REMOVAL OF PART CONCERNED




117754

- ☐ Drain the pump assembly reservoir using a syringe.
- □ Remove:
  - the earth strap on the pump assembly (11),
  - the lower bolts from the pump assembly (12),
  - the upper bolt from the pump assembly (13) .

**21B** 

K9K, and JA5



☐ Disconnect the connector from the pump assembly (14).

#### REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED

- Position the pump assembly.
- □ Refit:
  - the pump assembly upper bolt,
  - the pump assembly lower bolts,
  - the earth strap on the pump assembly.
- ☐ Tighten to torque:
  - -the pump assembly lower bolts (24 N.m),
  - -the pump assembly upper bolt (24 N.m).
- ☐ Connect the clutch control pipe on the hydraulic cylinder.
- ☐ Refit:
  - the low pressure pump pipe,
  - the high pressure pump pipe,

- the clutch pipe,
- the clutch pipe bracket,
- a new clip on the clutch pipe.
- ☐ Tighten to torque:
  - the low pressure pump pipe (14 N.m),
  - the high pressure pump pipe (14 N.m).
- ☐ Connect:
  - the actuator module connector,
  - the pump assembly connector.
- ☐ Refit the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (MR 392, 19D, Engine mounting).
- □ Remove the (Mot. 1453) and the safety strap(s).
- ☐ Refit:
  - the side stiffener bolts on the left-hand side of the vehicle,
  - the side stiffener on the left-hand side of the vehicle,

21B

#### K9K, and JA5

- -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- ☐ Connect the electrohydraulic unit connector.
- ☐ Fill the oil reservoir (see 21B, Sequential gearbox, Sequential gearbox oil: Specifications, page 21B-82) (Technical Note 6012, 04A, Lubricants) to between 32 and 38 mm above the MIN mark.

#### ☐ Refit:

- the Protection and Switching Unit,
- the wiring harness under the injection computer,
- -the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- -the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- the air filter box (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
- -the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the engine undertray.

#### **II - FINAL OPERATION**

- □ Perform the following operations:
  - bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84),
  - -the necessary programming (see **Fault finding Replacement of components** (MR 394, 21B, Sequential gearbox).

#### WARNING

21B

D4F, and JA3

Special tooling required	
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.

Equipment required
Diagnostic tool
safety strap(s)

Tightening torques ♡	
pump assembly lower bolts	24 N.m
pump assembly upper bolt	24 N.m
low pressure pump pipe	14 N.m
high pressure pump pipe	14 N.m

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

#### Note:

When replacing the electric pump assembly, always replace the control relay.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).

#### □ Remove:


- the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery),
- the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
- the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the scoop under the scuttle panel grille (see Scoop under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.




112211

- □ Remove the Protection and Switching Unit bolts (1).
- ☐ Remove:
  - the Protection and Switching Unit,
  - the wiring harness under the injection computer.

D4F, and JA3




- ☐ Fit the (Mot. 1453) with a safety strap(s).
- □ Remove:
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
  - the side stiffener bolts on the left-hand side of the vehicle.
  - the side stiffener on the left-hand side of the vehicle,
  - the engine undertray,
  - -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (MR 392, 19D, Engine mounting).



#### □ Disconnect:

- the connector (2) from the actuator module,
- the connector (3) from the pump assembly.


D4F, and JA3




114644

- ☐ Remove:
  - -the clutch pipe (4),
  - the clutch pipe bracket (5).
- ☐ Cut the clip on the clutch pipe (6).


D4F, and JA3






☐ Remove the high pressure pump pipe (7) and (8).

D4F, and JA3



114644


☐ Remove the low pressure pump pipe (9).



□ Disconnect the clutch control pipe (10) on the hydraulic cylinder by pushing on the clip.

D4F, and JA3

## II - OPERATION FOR REMOVAL OF PART CONCERNED




☐ Drain the pump assembly reservoir using a syringe.

#### □ Remove:

- the earth strap on the pump assembly (11),
- the lower bolts from the pump assembly (12),
- the upper bolt from the pump assembly (13) .

21B

D4F, and JA3



☐ Disconnect the connector from the pump assembly (14).

#### REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED

- Position the pump assembly.
- □ Refit:
  - the pump assembly upper bolt,
  - the pump assembly lower bolts,
  - the earth strap on the pump assembly.
- ☐ Tighten to torque:
  - -the pump assembly lower bolts (24 N.m),
  - -the pump assembly upper bolt (24 N.m).
- ☐ Connect the clutch control pipe on the hydraulic cylinder.
- ☐ Refit:
  - the low pressure pump pipe,
  - the high pressure pump pipe,

- the clutch pipe,
- the clutch pipe bracket,
- a new clip on the clutch pipe.
- ☐ Tighten to torque:
  - the low pressure pump pipe (14 N.m),
  - the high pressure pump pipe (14 N.m).
- ☐ Connect:
  - the actuator module connector,
  - the pump assembly connector.
- ☐ Refit the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (MR 392, 19D, Engine mounting).
- □ Remove the (Mot. 1453) and the safety strap(s).
- ☐ Refit:
  - the side stiffener bolts on the left-hand side of the vehicle,
  - the side stiffener on the left-hand side of the vehicle,

21B

#### D4F, and JA3

- -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- ☐ Connect the electrohydraulic unit connector.
- ☐ Fill the oil reservoir (see 21B, Sequential gearbox, Sequential gearbox oil: Specifications, page 21B-82) (Technical Note 6012, 04A, Lubricants) to between 32 and 38 mm above the MIN mark.

#### ☐ Refit:

- the Protection and Switching Unit,
- the wiring harness under the injection computer,
- -the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- -the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- the air filter box (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the engine undertray.

#### **II - FINAL OPERATION**

- □ Perform the following operations:
  - bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84)
  - -the necessary programming (see **Fault finding Replacement of components** (MR 394, 21B, Sequential gearbox).

#### WARNING



K9K, and JA5

## **Equipment required** Diagnostic tool

Tightening torques ♡	
solenoid valve bolts	4 N.m
bracket bolts on the actuator module	4 N.m

#### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

#### Note:

Before removing the solenoid valves, always mark their respective connectors in order not to mix them up.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the Diagnostic tool.

To discharge the accumulator, run command « Discharge pressure accumulator » AC081.


To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Remove the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).


#### **II - OPERATION FOR REMOVAL OF PART** CONCERNED



- □ Remove:
  - the bracket bolts on the actuator module (1),
  - the actuator module bracket (2).

21B

K9K, and JA5



- ☐ Remove the solenoid valve affected, following the correct removal order for the solenoid valves:
  - (1) Clutch solenoid valve
  - (2) Selection solenoid valve 4
  - (3) Selection solenoid valve 3
  - (4) Engagement solenoid valve 1

#### Note:

Remove engagement solenoid valve 2 (5) independently of the other solenoid valves.

#### REFITTING

#### I - REFITTING PREPARATION OPERATION

□ Refit the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).

### II - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the solenoid valve affected,
  - the bolts from the solenoid valve,
  - the actuator module bracket.
- ☐ Tighten to torque:
  - the solenoid valve bolts (4 N.m),

the bracket bolts on the actuator module (4 N.m).

#### **III - FINAL OPERATION**

- ☐ Perform the following operations:
  - bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84)
  - the necessary programming (see Fault finding -Replacement of components (MR 394, 21B, Sequential gearbox).

#### **WARNING**



D4F, and JA3

## **Equipment required** Diagnostic tool

Tightening torques ▽	
solenoid valve bolts	4 N.m
bracket bolts on the actuator module	4 N.m

#### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

#### Note:

Before removing the solenoid valves, always mark their respective connectors in order not to mix them up.

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the Diagnostic tool.

To discharge the accumulator, run command « Discharge pressure accumulator » AC081.


To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Remove the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).

#### **II - OPERATION FOR REMOVAL OF PART** CONCERNED




#### □ Remove:

- the bracket bolts on the actuator module (1),
- the actuator module bracket (2).



D4F, and JA3



- ☐ Remove the solenoid valve affected, following the correct removal order for the solenoid valves:
  - (1) Clutch solenoid valve
  - (2) Selection solenoid valve 4
  - (3) Selection solenoid valve 3
  - (4) Engagement solenoid valve 1

#### Note:

Remove engagement solenoid valve 2 (5) independently of the other solenoid valves.

#### REFITTING

#### I - REFITTING PREPARATION OPERATION

□ Refit the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34).

### II - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the solenoid valve affected,
  - the bolts from the solenoid valve,
  - the actuator module bracket.
- ☐ Tighten to torque:
  - the solenoid valve bolts (4 N.m),

the bracket bolts on the actuator module (4 N.m).

#### **III - FINAL OPERATION**

- ☐ Perform the following operations:
  - bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84)
  - the necessary programming (see Fault finding -Replacement of components (MR 394, 21B, Sequential gearbox).

#### **WARNING**

### **Engagement sensor: Removal - Refitting**



K9K, and JA5


Т	ightening torques ♡	
engagement bolts	sensor	4 Nm

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove the front left-hand wheel (see Wheel: Removal Refitting) (MR 392, 35A, Wheels and tyres).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



17978

- ☐ Disconnect the engagement sensor connector.
- □ Remove:
  - the engagement sensor bolts,
  - the engagement sensor (1).

#### REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the engagement sensor,
  - the engagement sensor bolts.
- ☐ Tighten to torque the engagement sensor bolts (4 Nm).
- ☐ Connect the engagement sensor connector.

#### **II - FINAL OPERATION.**

- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Refit the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres).
- □ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).

#### **WARNING**

### **Engagement sensor: Removal - Refitting**



D4F, and JA3


Т	ightening torques ♡	
engagement bolts	sensor	4 Nm

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove the front left-hand wheel (see Wheel: Removal Refitting) (MR 392, 35A, Wheels and tyres).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



17978

- ☐ Disconnect the engagement sensor connector.
- □ Remove:
  - the engagement sensor bolts,
  - the engagement sensor (1).

#### REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the engagement sensor,
  - the engagement sensor bolts.
- ☐ Tighten to torque the engagement sensor bolts (4 Nm).
- ☐ Connect the engagement sensor connector.

#### **II - FINAL OPERATION.**

- □ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Refit the front left-hand wheel (see Wheel: Removal Refitting) (MR 392, 35A, Wheels and tyres).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).

#### **WARNING**




K9K, and JA5

Special tooling required	
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.

Equipment required
Diagnostic tool
safety strap(s)

Tightening torques ♡	
clutch pipe nuts	14 Nm
high pressure pump pipe nuts	14 Nm
gearbox mounting nut	21 Nm

Tightening torques ▽		
actuator module nuts	24 Nm	
bolts mounting the left- hand suspended mount- ing on the gearbox	62 Nm	
stud mounting the left- hand suspended mount- ing on the gearbox (if it has been changed)	180 Nm	
bolts mounting the left- hand suspended mount- ing on the body	62 Nm	
gearbox left-hand rub- ber pad nut	62 Nm	



(1) Clutch solenoid valve

(2) Gear engagement solenoid valve

(18) Gear engagement solenoid valve

(4) Selection solenoid valve

21B

#### K9K, and JA5

(5) Engagement sensor
(20) Gear selection sensor
(7) Solenoid valve unit pressure sensor
(8) High pressure filter

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

\_

**IMPORTANT** 

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).

#### □ Remove:


- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- -the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
- -the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment).
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.



☐ Remove the Protection and Switching Unit (9).

#### ☐ Remove:

- the Protection and Switching Unit,
- the wiring harness under the injection computer.



118429


☐ Fit the (Mot. 1453) with a safety strap(s).

#### □ Remove:

- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the side stiffener bolts on the left-hand side of the vehicle,
- the side stiffener on the left-hand side of the vehicle,


K9K, and JA5

- the engine undertray.



#### ☐ Remove:


- the nut (10) from the gearbox left-hand rubber pad,
- the bolts (11) from the left-hand suspended mounting on the body,
- the left-hand suspended mounting from the body,
- the bolts (12) from the gearbox left-hand suspended mounting,
- the gearbox left-hand suspended mounting.



#### □ Disconnect:

- the connector from the actuator module (13),
- the connector from the pump assembly (14) .


K9K, and JA5




114644

- □ Remove:
  - -the clutch pipe (15),
  - the clutch pipe bracket (16) .
- ☐ Cut the clip on the clutch pipe (17).


K9K, and JA5





☐ Remove the high pressure pump pipes (18) and (20)

K9K, and JA5



114644

#### ☐ Remove the low pressure pump pipe (20).

#### Note:

To avoid any sequential gearbox malfunction, mark the routing for the solenoid valve and sensor wiring on the actuator module.

## II - OPERATION FOR REMOVAL OF PART CONCERNED

#### Note:

The actuator module can be removed or refitted with the pressure accumulator in place.


#### ☐ Remove:

- the lifting eye on the gearbox,
- the nuts from the actuator module.


21B

K9K, and JA5


#### **Actuator module**




#### Selector shaft locked



#### Selector shaft unlocked




☐ Unlock the gear selector shaft (21) by turning the shaft by a quarter of a turn using a screwdriver.




☐ Disconnect the sequential gearbox sensor connector (22).

K9K, and JA5




☐ Remove the nuts (23) from the electro-hydraulic unit.




- ☐ Remove:
  - the lifting eye nut on the actuator module,
  - the lifting eye (24) on the actuator module,
  - the actuator module.

## I - REFITTING PREPARATIONS OPERATION

□ Check that the two half-moons are positioned correctly.



- ☐ Position the two half-moons and the circlips in the selector shaft neck.
- ☐ Coat the two half-moons and the selector finger with MOLYCOTE.




- □ Lock the selector shaft (25).
- □ Position the flat seal.

21B

K9K, and JA5

## II - REFITTING OPERATION FOR PART CONCERNED



1797

- ☐ Using a screwdriver, press on the selector shaft to clip it onto the actuator module.
- □ Refit:
  - the low pressure pump pipe,
  - the high pressure pump pipe,
  - the clutch pipe,
  - the clutch pipe bracket,
  - a new clip on the clutch pipe,
  - the nuts from the actuator module.
- ☐ Without tightening, fit:
  - the clutch pipe nuts,
  - the high pressure pump pipe nuts.
- ☐ Torque tighten:
  - the clutch pipe nuts (14 Nm),
  - -the high pressure pump pipe nuts (14 Nm),
  - the gearbox mounting nut (21 Nm),
  - the actuator module nuts (24 Nm).
- ☐ Connect the sequential gearbox speed sensor connector.

- ☐ Remove the (Mot. 1453) and the safety strap(s).
- ☐ Reposition the left-hand suspended mounting on the gearbox.
- ☐ Refit the bolts mounting the left-hand suspended mounting on the gearbox.
- ☐ Torque tighten:
  - the bolts mounting the left-hand suspended mounting on the gearbox (62 Nm),
  - the stud mounting the left-hand suspended mounting on the gearbox (if it has been changed) (180 Nm)
- ☐ Reposition the left-hand suspended mounting on the body.
- ☐ Refit the left-hand suspended mounting bolts on the body.
- ☐ Torque tighten:
  - the bolts mounting the left-hand suspended mounting on the body (62 Nm),
  - the gearbox left-hand rubber pad nut (62 Nm).
- ☐ Refit:
  - the side stiffener bolts on the left-hand side of the vehicle.
  - the side stiffener on the left-hand side of the vehicle.
  - the front left-hand wheel arch liner (see **Front** wheel arch liner: Removal Refitting) (MR 393, 55A, Exterior protection).
  - the engine undertray,
  - the Protection and Switching Unit,
  - the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
  - the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
  - the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),

21B

K9K, and JA5

## **III - FINAL OPERATION.**

☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394, 21B, Sequential gearbox).

## **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.




D4F, and JA3

Special tooling required		
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.	

Equipment required
Diagnostic tool
safety strap(s)

Tightening torques ♡	
clutch pipe nuts	14 Nm
high pressure pump pipe nuts	14 Nm
gearbox mounting nut	21 Nm

Tightening torques ♡	
actuator module nuts	24 Nm
bolts mounting the left- hand suspended mount- ing on the gearbox	62 Nm
stud mounting the left- hand suspended mount- ing on the gearbox (if it has been changed)	180 Nm
bolts mounting the left- hand suspended mount- ing on the body	62 Nm
gearbox left-hand rub- ber pad nut	62 Nm



17979

(2) Gear engagement solenoid valve

(3) Gear engagement solenoid valve

(4) Selection solenoid valve

21B

## D4F, and JA3

(5)	Engagement sensor
(6)	Gear selection sensor
(7)	Solenoid valve unit pressure sensor
(8)	High pressure filter

## **REMOVAL**

## I - REMOVAL PREPARATION OPERATION

## **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic tool**.

To discharge the accumulator, run command « Discharge pressure accumulator » AC081.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).

## □ Remove:


- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).
- -the scuttle panel grille (see **Scuttle panel grille: Removal Refitting**) (MR 393, 56A, Exterior equipment),
- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment).
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.



☐ Remove the Protection and Switching Unit bolts (9).

### ☐ Remove:

- the Protection and Switching Unit,
- the wiring harness under the injection computer.



118429

☐ Fit the (Mot. 1453) with a safety strap(s).


#### □ Remove:

- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the side stiffener bolts on the left-hand side of the vehicle,
- the side stiffener on the left-hand side of the vehicle,



D4F, and JA3


- the engine undertray.



109952

## ☐ Remove:


- the nut (10) from the gearbox left-hand rubber pad,
- the bolts (11) from the left-hand suspended mounting on the body,
- the left-hand suspended mounting from the body,
- the bolts (12) from the gearbox left-hand suspended mounting,
- the gearbox left-hand suspended mounting.



## □ Disconnect:

- the connector from the actuator module (13),
- the connector from the pump assembly (14) .

D4F, and JA3





114644

## □ Remove:

- -the clutch pipe (15),
- the clutch pipe bracket (16) .
- ☐ Cut the clip on the clutch pipe (17).


D4F, and JA3





☐ Remove the high pressure pump pipes (18) and (19)

D4F, and JA3



114644

## ☐ Remove the low pressure pump pipe (20).

## Note:

To avoid any sequential gearbox malfunction, mark the routing for the solenoid valve and sensor wiring on the actuator module.

## **II - OPERATION FOR REMOVAL OF PART CONCERNED**

## Note:


The actuator module can be removed or refitted with the pressure accumulator in place.

## ☐ Remove:

- the lifting eye on the gearbox,
- the nuts from the actuator module.


D4F, and JA3

## **Actuator module**




117749


## Selector shaft locked



Selector shaft unlocked




☐ Unlock the gear selector shaft by turning the shaft (21) by a quarter of a turn using a screwdriver.




☐ Disconnect the sequential gearbox speed sensor connector (22).

21B

D4F, and JA3



☐ Remove the nuts (23) from the electro-hydraulic unit




## ☐ Remove:

- the lifting eye nut on the actuator module,
- the lifting eye (24) on the actuator module,
- the actuator module.


## **REFITTING**

## I - REFITTING PREPARATIONS OPERATION

□ Check that the two half-moons are positioned correctly.



- ☐ Position the two half-moons and the circlips in the selector shaft neck.
- ☐ Coat the two half-moons and the selector finger with MOLYCOTE.




- □ Lock the selector shaft (25).
- □ Position the flat seal.



D4F, and JA3

## II - REFITTING OPERATION FOR PART CONCERNED



17970

- ☐ Using a screwdriver, press on the selector shaft to clip it onto the actuator module.
- □ Refit:
  - the low pressure pump pipe,
  - the high pressure pump pipe,
  - the clutch pipe,
  - the clutch pipe bracket,
  - a new clip on the clutch pipe,
  - the nuts from the actuator module.
- ☐ Without tightening, fit:
  - the clutch pipe nuts,
  - the high pressure pump pipe nuts.
- ☐ Torque tighten:
  - the clutch pipe nuts (14 Nm),
  - -the high pressure pump pipe nuts (14 Nm),
  - the gearbox mounting nut (21 Nm),
  - the actuator module nuts (24 Nm).
- ☐ Connect the sequential gearbox speed sensor connector.

- ☐ Remove the (Mot. 1453) and the safety strap(s).
- ☐ Reposition the left-hand suspended mounting on the gearbox.
- ☐ Refit the bolts mounting the left-hand suspended mounting on the gearbox.
- ☐ Torque tighten:
  - the bolts mounting the left-hand suspended mounting on the gearbox (62 Nm),
  - the stud mounting the left-hand suspended mounting on the gearbox (if it has been changed) (180 Nm)
- ☐ Reposition the left-hand suspended mounting on the body.
- ☐ Refit the left-hand suspended mounting bolts on the body.
- ☐ Torque tighten:
  - the bolts mounting the left-hand suspended mounting on the body (62 Nm),
  - the gearbox left-hand rubber pad nut (62 Nm).
- □ Refit:
  - the side stiffener bolts on the left-hand side of the vehicle.
  - the side stiffener on the left-hand side of the vehicle.
  - the front left-hand wheel arch liner (see **Front** wheel arch liner: Removal Refitting) (MR 393, 55A, Exterior protection).
  - the engine undertray,
  - the Protection and Switching Unit,
  - the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
  - the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
  - the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),

21B

D4F, and JA3

## **III - FINAL OPERATION.**

☐ Carry out the necessary programming (see Fault finding - Replacement of components) (MR 394, 21B, Sequential gearbox).

## **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

Gear selection sensor: Removal - Refitting

21B

K9K, and JA5

Tightening torques ▽	
gear selection sensor bolts	4 Nm

## **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION


### **WARNING**

To remove the gear selection sensor it is essential that you shift to first gear before removal.

#### □ Remove:

- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit**: **Removal Refitting**) (MR 392, 12A, Fuel mixture).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



117749

- ☐ Disconnect the gear selection sensor connector (1).
- □ Remove:
  - the gear selection sensor bolts,
  - the gear selection sensor (1).

## REFITTING

### I - REFITTING PREPARATIONS OPERATION

☐ Check that the gear selection sensor is able to rotate freely.

## II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit:
  - the gear selection sensor,
  - the gear selection sensor bolts.
- ☐ Torque tighten the **gear selection sensor bolts (4 Nm)**.
- ☐ Connect the gear selection sensor connector.

- ☐ Refit:
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- ☐ Carry out the necessary programming (see Fault finding Replacement of components (MR 394, 21B, Sequential gearbox).

## Gear selection sensor: Removal - Refitting



D4F, and JA3

	Tiç	ghtening torques 🗇	
gear bolts	selection	sensor	4 Nm

## **REMOVAL**

## I - REMOVAL PREPARATION OPERATION


### **WARNING**

To remove the gear selection sensor it is essential that you shift to first gear before removal.

### □ Remove:

- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



117749

- ☐ Disconnect the gear selection sensor connector (1).
- □ Remove:
  - the gear selection sensor bolts,
  - the gear selection sensor (1).

## REFITTING

### I - REFITTING PREPARATIONS OPERATION

☐ Check that the gear selection sensor is able to rotate freely.

## II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit:
  - the gear selection sensor,
  - the gear selection sensor bolts.
- ☐ Torque tighten the **gear selection sensor bolts (4** Nm).
- ☐ Connect the gear selection sensor connector.

- □ Refit:
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Carry out the necessary programming (see Fault finding - Replacement of components (MR 394, 21B, Sequential gearbox).

## SEQUENTIAL GEARBOX Clutch position sensor: Removal - Refitting

21B


K9K, and JA5

## **REMOVAL**

## I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



114150

- ☐ Remove the engine undertray.
- ☐ Disconnect the clutch position sensor connector.
- ☐ Remove:
  - the bolts (1) from the clutch position sensor,
  - the clutch position sensor (2) .

## REFITTING

## I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the clutch position sensor,
  - the clutch position sensor bolts.
- ☐ Connect the clutch position sensor connector.

- ☐ Refit the engine undertray.
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components (MR 394, 21B, Sequential gearbox).

## SEQUENTIAL GEARBOX Clutch position sensor: Removal - Refitting

**21B** 


D4F, and JA3

## **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



114150

- ☐ Remove the engine undertray.
- ☐ Disconnect the clutch position sensor connector.
- ☐ Remove:
  - the clutch position sensor bolt (1),
  - the clutch position sensor (2).

## **REFITTING**

## I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit:
  - the clutch position sensor,
  - the clutch position sensor bolts.
- ☐ Connect the clutch position sensor connector.

- ☐ Refit the engine undertray.
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components (MR 394, 21B, Sequential gearbox).

Solenoid valve assembly pressure sensor: Removal - Refitting

21B

K9K, and JA5

## Equipment required Diagnostic tool

solenoid valve unit pressure sensor 15 Nm

## REMOVAL

#### REMOVAL PREPARATION OPERATION

### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic tool**.


To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Remove:
  - -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
  - the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).



- ☐ Disconnect the solenoid valve unit pressure sensor
- ☐ Remove the pressure sensor from the solenoid valve unit (1) using a **long socket**.

## **REFITTING**

connector (1).

## I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the solenoid valve unit pressure sensor.
- ☐ Finger tighten the solenoid valve unit pressure sensor.
- ☐ Torque tighten the solenoid valve unit pressure sensor (15 Nm)
- Connect the solenoid valve unit pressure sensor connector.

- ☐ Refit:
  - the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

Solenoid valve assembly pressure sensor: Removal - Refitting

21B

K9K, and JA5

☐ Carry out the necessary programming (see Fault finding - Replacement of components (MR 394, 21B, Sequential gearbox).

## **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

Solenoid valve assembly pressure sensor: Removal - Refitting

21B

D4F, and JA3

## **Equipment required**

Diagnostic tool

## 

solenoid valve unit pressure sensor 15 Nm

### REMOVAL

#### REMOVAL PREPARATION OPERATION

### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic tool**.


To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Remove:
  - -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
  - -the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery).



- ☐ Disconnect the solenoid valve unit pressure sensor connector (1).
- □ Remove the pressure sensor from the solenoid valve unit (1) using a **long socket**.

### REFITTING

## I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the solenoid valve unit pressure sensor.
- ☐ Finger tighten the solenoid valve unit pressure sensor.
- □ Torque tighten the solenoid valve unit pressure sensor (15 Nm)
- □ Connect the solenoid valve unit pressure sensor connector.

- ☐ Refit:
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
  - the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

Solenoid valve assembly pressure sensor: Removal - Refitting

21B

D4F, and JA3

☐ Carry out the necessary programming (see Fault finding - Replacement of components (MR 394, 21B, Sequential gearbox).

## **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

Sequential gearbox engine speed sensor: Removal - Refitting

D4F, and JA3

Equipment required
Diagnostic tool

Tightening torques ▽	
sequential gearbox speed sensor	15 Nm
the left-hand sus- pended engine mount- ing support bolts on the gearbox	62 Nm

### REMOVAL

## I - REMOVAL PREPARATION OPERATION

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the Diagnostic tool.

To discharge the accumulator, run command « Discharge pressure accumulator » AC081.

To confirm the pressure drop, read the « Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).


## **II - OPERATION FOR REMOVAL OF PART CONCERNED**

☐ Remove the electro-hydraulic unit (see 21B, Sequential gearbox, Electro-hydraulic unit: Removal - Refitting, page 21B-8).



#### □ Remove:

- the mounting bolts (1) from the left-hand suspended mounting on the gearbox,
- the left-hand suspended engine mounting (2) on the gearbox.



- ☐ Disconnect the sequential gearbox speed sensor connector.
- □ Remove:
  - the sequential gearbox speed sensor bolt,
  - the sequential gearbox speed sensor (3).

21B

Sequential gearbox engine speed sensor: Removal - Refitting

D4F, and JA3

- REFITTING OPERATION FOR PART DNCERNED
Connect the sequential gearbox speed sensor connector.
Refit:
- the sequential gearbox engine speed sensor,
- the sequential gearbox sensor bolt.
Torque tighten the sequential gearbox speed sensor (15 $\rm Nm$ ).
Refit:
- the left-hand suspended engine mounting support on the gearbox,
- the left-hand suspended engine mounting support bolts on the gearbox.
Torque tighten the <b>the left-hand suspended en-</b> <b>gine mounting support bolts on the gearbox (62</b> <b>Nm)</b> .
Refit the electro-hydraulic unit (see 21B, Sequential gearbox, Electro-hydraulic unit: Removal - Refitting, page 21B-8).
Connect the battery (see <b>Battery: Removal - Refitting</b> ) (MR 392, 80A, Battery).
Carry out the necessary programming (see <b>Fault finding - Replacement of components</b> ) (MR 394, 21B, Sequential gearbox).
WARNING
After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the <b>MIN</b> mark.

Sequential gearbox engine speed sensor: Removal - Refitting

21B

K9K, and JA5

## Equipment required Diagnostic tool

Tightening torques ▽	
sequential gearbox speed sensor	15 Nm
the left-hand sus- pended engine mount- ing support bolts on the gearbox	62 Nm

### REMOVAL

## I - REMOVAL PREPARATION OPERATION

#### **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.


If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).


## II - OPERATION FOR REMOVAL OF PART CONCERNED

□ Remove the electro-hydraulic unit (see 21B, Sequential gearbox, Electro-hydraulic unit: Removal - Refitting, page 21B-8).



#### □ Remove:

- the mounting bolts (1) from the left-hand suspended mounting on the gearbox,
- the left-hand suspended engine mounting (2) on the gearbox.



Disconnect the sequential gearbox speed sensor connector.

## □ Remove:

- the sequential gearbox speed sensor bolt,
- the sequential gearbox speed sensor (3) .

Sequential gearbox engine speed sensor: Removal - Refitting

21B

K9K, and JA5

III - REFITTING OPERATION FOR PART CONCERNED			
	Refit:		
	- the sequential gearbox engine speed sensor,		
	- the sequential gearbox sensor bolt.		
	Connect the sequential gearbox speed sensor connector.		
	Torque tighten the sequential gearbox speed sensor (15 $\rm Nm$ ).		
	Refit:		
	- the left-hand suspended engine mounting support on the gearbox,		
	- the left-hand suspended engine mounting support bolts on the gearbox.		
	Torque tighten the <b>the left-hand suspended engine mounting support bolts on the gearbox (62 Nm)</b> .		
	Refit the electro-hydraulic unit (see 21B, Sequential gearbox, Electro-hydraulic unit: Removal - Refitting, page 21B-8).		
	Connect the battery (see <b>Battery: Removal - Refitting</b> ) (MR 392, 80A, Battery).		
	Carry out the necessary programming (see <b>Fault finding - Replacement of components</b> ) (MR 394, 21B, Sequential gearbox).		
	WARNING		
	After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the <b>MIN</b> mark		

## Sequential gearbox: Removal - Refitting

21B

K9K, and JA5

# Mot. 1453 Engine anchorage support with multiple adjustments and retaining straps.

Equipment required
Diagnostic tool
safety strap(s)
component jack

	7	ightening torques 🗇	
gearbox bolts	bell	housing	44 N.m

### REMOVAL

### I - REMOVAL PREPARATION OPERATION

## **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the « Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).


#### □ Remove:

- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).

- the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- the engine undertray.
- ☐ Drain the sequential gearbox.

#### □ Remove:


- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9),
- the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
- the diesel injection computer (see Diesel injection computer: Removal - Refitting) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.




112211

- ☐ Remove the Protection and Switching Unit bolts (1).
- □ Remove:
  - the Protection and Switching Unit,
  - the wiring harness under the injection computer.

K9K, and JA5



- ☐ Fit the (Mot. 1453) with a safety strap(s).
- □ Remove:
  - -the side stiffener bolts on the left-hand side of the vehicle,
  - the side stiffener on the left-hand side of the vehicle,
  - the engine undertray,
  - -the rear suspended engine mounting (see 19D, Engine mounting, Rear suspended engine mounting: Removal-Refitting),
  - -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal Refitting, page 21B-34),
  - -the pump assembly (see 21B, Sequential gearbox, Sequential gearbox: Removal Refitting, page 21B-66).



☐ Attach the « cooling radiator - fan unit » assembly to the upper cross member using a **safety strap(s)**.


## □ Remove:

- the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection),
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure).



K9K, and JA5


## II - OPERATION FOR REMOVAL OF PART CONCERNED



1

## ☐ Remove:


- the stud (2) from the actuator module on the gearbox.
- the wiring harness channel bolts on the gearbox,
- the earth wiring bolt on the gearbox.



117751

- ☐ Disconnect the engine speed and position sensor connector.
- □ Remove:
  - the bolt from the engine speed and position sensor,

- the engine speed and position sensor (3) .




## □ Remove:

- the exhaust bracket bolt on the gearbox,
- the exhaust bracket nut on the gearbox,
- the exhaust bracket (4) on the gearbox,
- the starter bolts,
- the gearbox upper bolts,
- the gearbox lower bolts.

## Sequential gearbox: Removal - Refitting




K9K, and JA5



- ☐ Position the component jack (5) under the gear-
- ☐ Remove the gearbox.

## REFITTING

### I - REFITTING PREPARATION OPERATION



108796

☐ Check that the engine/gearbox centring rings are in place and correctly positioned (6).

## **WARNING**

To avoid damaging the slave cylinder, do not coat the gearbox output shaft with grease.

## **WARNING**

To prevent leaks, replace the slave cylinder after replacing the clutch pressure plate.

### Note:

- Always replace the right-hand driveshaft snap ring with a new one whenever it is removed.
- Always replace the differential output seals each time the driveshafts are removed.

## **II - REFITTING OPERATION FOR PART CONCERNED**

- ☐ Refit:
  - the gearbox,
  - the gearbox lower bolts,
  - the gearbox upper bolts,
  - the actuator module stud on the gearbox.

21B

K9K, and JA5

☐ Torque tighten the **gearbox bell housing bolts (44 N.m)**.

#### **III - FINAL OPERATION**

- □ Refit:
  - the starter bolts,
  - the wiring channel bolts on the gearbox,
  - the earth wiring bolt on the gearbox,
  - the exhaust bracket bolt on the gearbox,
  - the speed and position sensor,
  - the exhaust bracket on the gearbox,
  - the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12),
  - -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal Refitting, page 21B-34),
  - -the rear suspended engine mounting (see **Lower engine tie-bar: Removal Refitting**) (MR 392, 19D, Engine mounting),
- ☐ Remove the (Mot. 1453) and the safety strap(s).
- ☐ Bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84)
- ☐ Refit:
  - the side stiffener bolts on the left-hand side of the vehicle,
  - the side stiffener on the left-hand side of the vehicle.
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
  - the Protection and Switching Unit,
  - the wiring harness under the injection computer,
  - the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
  - -the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
  - -the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
  - the air filter box (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),

- the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the front left-hand wheel (see **Wheel: Removal - Refitting**) (MR 392, 35A, Wheels and tyres),
- the engine undertray,
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure),
- the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection).
- ☐ Fill the electro-hydraulic unit reservoir with oil (see 21B, Sequential gearbox, Sequential gearbox oil: Specifications, page 21B-82) (Technical Note 6012, 04A, Lubricants) to between 32 and 38 mm above the MIN mark.
- ☐ Perform the following operations:
  - the necessary programming (see Fault finding -Replacement of components (MR 394, 21B, Sequential gearbox).

#### **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

21B

D4F, and JA3

# Mot. 1453 Engine anchorage support with multiple adjustments and retaining straps.

Equipment required
Diagnostic tool
safety strap(s)
component jack

Tightening torques ♡	
gearbox bolts	44 N.m

## **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

## **IMPORTANT**

Before any operation on the sequential system, discharge the accumulator using the **Diagnostic** tool.

To discharge the accumulator, run command « Discharge pressure accumulator » **AC081**.

To confirm the pressure drop, read the «Hydraulic pressure » parameter for the resulting value.

If there is still pressure in the accumulator, re-run the « Discharge pressure accumulator » command until the pressure is negligible and will not pose a risk when the high pressure pipes are removed.

The pressure reading must be close to zero.

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).


## □ Remove:

- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery),
- -the scuttle panel grille (see **Scuttle panel grille: Removal Refitting**) (MR 393, 56A, Exterior equipment),

- the scoop under the scuttle panel grille (see Scoop under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment),
- the engine undertray.
- ☐ Drain the sequential gearbox.

#### □ Remove:


- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9),
- the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal -Refitting, page 29A-2),
- the diesel injection computer (see Diesel injection computer: Removal - Refitting) (MR 392, 13B, Diesel injection),
- the wiring harness nut under the injection computer.




112211

- ☐ Remove the Protection and Switching Unit bolts (1).
- □ Remove:
  - the Protection and Switching Unit,
  - the wiring harness under the injection computer.

D4F, and JA3



- ☐ Fit the (Mot. 1453) with a safety strap(s).
- □ Remove:
  - the side stiffener bolts on the left-hand side of the vehicle,
  - the side stiffener on the left-hand side of the vehicle.
  - the engine undertray,
  - -the rear suspended engine mounting (see **Lower engine tie-bar: Removal Refitting**) (MR 392, 19D, Engine mounting),
  - -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal Refitting, page 21B-34),
  - -the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12).



☐ Attach the « cooling radiator - fan unit » assembly to the upper cross member using a **safety strap(s)**.


#### □ Remove:

- the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection),
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure).


**21B** 

D4F, and JA3

## II - OPERATION FOR REMOVAL OF PART CONCERNED




☐ Remove the stud (2) from the actuator module on the gearbox.



☐ Lift the cooling hose (3) to access the wiring harness channel bolts on the gearbox.

## ☐ Remove:


- the wiring harness channel bolts on the gearbox,
- the earth wiring bolt on the gearbox.



☐ Disconnect the engine speed and position sensor connector.

## □ Remove:

- the bolt from the engine speed and position sensor,
- the engine speed and position sensor (4) .




## Remove:

- the flywheel protector bolt (6),
- the flywheel protector (5),
- the starter bolts,
- the gearbox upper bolts,



D4F, and JA3


- the gearbox lower bolts.



- ☐ Position the component jack (7) under the gear-
- ☐ Remove the gearbox.

## REFITTING

## I - REFITTING PREPARATION OPERATION



☐ Check that the engine/gearbox centring rings are in place and correctly positioned (8).

## **WARNING**

To avoid damaging the slave cylinder, do not coat the gearbox output shaft with grease.

## **WARNING**

To prevent leaks, replace the slave cylinder after replacing the clutch pressure plate.

### Note:

- Always replace the right-hand driveshaft snap ring with a new one whenever it is removed.
- Always replace the differential output seals each time the driveshafts are removed.
- Always replace the hydraulic clutch thrust bearing.

## **II - REFITTING OPERATION FOR PART CONCERNED**

- ☐ Refit:
  - the gearbox,
  - the gearbox lower bolts,

21B

## D4F, and JA3

- the gearbox upper bolts,
- the actuator module stud on the gearbox.
- ☐ Torque tighten the **gearbox bolts (44 N.m)**.

### **III - FINAL OPERATION**

### □ Refit:

- the starter bolts,
- the wiring channel bolts on the gearbox,
- the earth wiring bolt on the gearbox,
- the flywheel protector,
- the speed and position sensor,
- the pump assembly (see 21B, Sequential gearbox, Pump assembly: Removal - Refitting, page 21B-12),
- -the actuator module (see 21B, Sequential gearbox, Actuator module: Removal - Refitting, page 21B-34),
- -the rear suspended engine mounting (see **Lower engine tie-bar: Removal Refitting**) (MR 392, 19D, Engine mounting),
- ☐ Remove the (Mot. 1453) and the safety strap(s).
- □ Bleed the clutch circuit (see 21B, Sequential gearbox, Sequential gearbox: Bleeding, page 21B-84)

#### ☐ Refit:

- the side stiffener bolts on the left-hand side of the vehicle.
- the side stiffener on the left-hand side of the vehicle.
- -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection).
- the Protection and Switching Unit,
- the wiring harness under the injection computer,
- the diesel injection computer (see **Diesel injection computer: Removal Refitting**) (MR 392, 13B, Diesel injection),
- -the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- -the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
- the air filter box (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),

- the battery tray (see Battery tray: Removal Refitting) (MR 392, 80A, Battery),
- the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery),
- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- the engine undertray,
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure),
- the front bumper (see **Front bumper: Removal Refitting**) (MR 393, 55A, Exterior protection).
- ☐ Fill the electro-hydraulic unit reservoir with oil (see 21B, Sequential gearbox, Sequential gearbox oil: Specifications, page 21B-82) (Technical Note 6012, 04A, Lubricants) to between 32 and 38 mm above the MIN mark.
- □ Perform the following operations:
  - the necessary programming (see Fault finding -Replacement of components (MR 394, 21B, Sequential gearbox).

## **WARNING**

After the accumulator has been fully filled (15 seconds after the ignition has been switched on): the oil is at the **MIN** mark.

## Sequential gearbox converter: Removal - Refitting




K9K, and JA5

## **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- □ Remove:
  - -the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front wheel arch liner (see Front wheel arch liner: Removal Refitting) (MR 393, 55A, Wheel arch liner).

## II - OPERATION FOR REMOVAL OF PART CONCERNED



117755

### □ Remove:

- -the retaining belt (1) from the sequential gearbox computer,
- the sequential gearbox computer connector (2),
- the sequential gearbox computer (3) .

## REFITTING

## I - REFITTING OPERATION FOR PART CONCERNED

### ☐ Refit:

- the sequential gearbox computer,
- the sequential gearbox computer connector,
- the retaining belt from the sequential gearbox computer,

### II - FINAL OPERATION.

### □ Refit:

- the front wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Wheel arch liner).
- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- ☐ Connect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).

### Sequential gearbox converter: Removal - Refitting




D4F, and JA3

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove:
  - -the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Wheel arch liner).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



117755

#### □ Remove:

- -the retaining belt  $(\mathbf{1})$  from the sequential gearbox computer,
- the sequential gearbox computer connector (2) ,
- the sequential gearbox computer (3) .

#### REFITTING

## I - REFITTING OPERATION FOR PART CONCERNED

#### ☐ Refit:

- the sequential gearbox computer,
- the sequential gearbox computer connector,
- the retaining belt from the sequential gearbox computer,

#### II - FINAL OPERATION.

#### Refit:

- the front wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Wheel arch liner).
- the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).

## Sequential gearbox gear lever: Removal - Refitting




K9K, and JA5

#### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

□ Disconnect the battery (see **Battery: Removal - Refitting**) (MR 392, 80A, Battery).

# II - OPERATION FOR REMOVAL OF PART CONCERNED




☐ Remove the gear lever cover (1) using a screwdriver



□ Disconnect the gear lever lighting connector (2).






#### ☐ Remove:

- the rear bolts (3) from the centre console,
- the front bolts (4) from the centre console.


## Sequential gearbox gear lever: Removal - Refitting




K9K, and JA5



☐ Remove the soundproofing (5) from the gear lever.



- □ Detach the connector (6) from the gear lever.
- ☐ Disconnect the gear lever connector.



- □ Remove:
  - the bolts (7) from the gear lever base plate,
  - the gear lever.

#### **REFITTING**

## I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit:
  - the gear lever,
  - the gear lever base plate bolts,
- ☐ Connect the gear lever connector.
- ☐ Attach the gear lever connector.
- Refit:
  - the gear lever soundproofing,
  - the front bolts to the centre console,
  - the rear bolts to the centre console.
- ☐ Connect the gear lever lighting connector.
- ☐ Refit the gear lever cover.

#### **II - FINAL OPERATION.**

- □ Connect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).

## Sequential gearbox gear lever: Removal - Refitting




D4F, and JA3

#### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

□ Disconnect the battery (see **Battery: Removal - Refitting**) (MR 392, 80A, Battery).

# II - OPERATION FOR REMOVAL OF PART CONCERNED




☐ Remove the gear lever cover (1) using a screwdriver



□ Disconnect the gear lever lighting connector (2).






#### □ Remove:

- the rear bolts (3) from the centre console,
- the front bolts (4) from the centre console.


## Sequential gearbox gear lever: Removal - Refitting




D4F, and JA3



☐ Remove the soundproofing (5) from the gear lever.



- □ Detach the connector (6) from the gear lever.
- ☐ Disconnect the gear lever connector.



- □ Remove:
  - the bolts (7) from the gear lever base plate,
  - the gear lever.

#### **REFITTING**

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit:
  - the gear lever,
  - the gear lever base plate bolts,
- ☐ Connect the gear lever connector.
- ☐ Attach the gear lever connector.
- Refit:
  - the gear lever soundproofing,
  - the front bolts to the centre console,
  - the rear bolts to the centre console.
- ☐ Connect the gear lever lighting connector.
- ☐ Refit the gear lever cover.

#### **II - FINAL OPERATION.**

- □ Connect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- ☐ Carry out the necessary programming (see Fault finding Replacement of components) (MR 394, 21B, Sequential gearbox).


## **SEQUENTIAL GEARBOX** Sequential gearbox oil: Specifications



5-SPEED MANUAL SEQUENTIAL GEARBOX

#### I - GEARBOX TYPE/OIL TYPE CORRELATIONS:

GEARBOX TYPE	TYPE OF OIL FOR GEAR- BOX	TYPE OF OIL FOR SEQUEN- TIAL UNIT	TYPE OF HYDRAULIC CLUTCH CON- TROL FLUID
JH1	TRANSELF TRJ 75W80 or NFJ75W80	ELF RENAULT- MATIC D3 SYN (3)	1
JA3/JA5	TRANSELF TRJ 75W80 or NFJ75W80	ELF SPEEDMATIC (1)	DOT4 (2)
PA0/PA6	TRANSELF TRX 75W80 or NFP75W80	ELF SPEEDMATIC (1)	DOT4 <b>(2)</b>



# **SEQUENTIAL GEARBOX**Sequential gearbox oil: Specifications

21B

5-SPEED MANUAL SEQUENTIAL GEARBOX

II - STANDARDS AND PART NUMBERS OF THE VARIOUS RECOMMENDED OILS:

DESIGNATION	STANDARD	PART NUMBER
TRANSELF	APIGL4	77 11 143 534
TRX 75W80	MIL-L-2105	(5 litres)
OR	C or D	
NFP75W80		
TRANSELF	APIGL4	May be ordered from
TRJ 75W80	MIL-L-2105	ELF
or	C or D	
NFJ 75W80		
ELF	DEXRON III	May be ordered from
RENAULTMATIC		ELF
D3 SYN		
ELF	ATF	77 11 228 107
SPEEDMATIC		(1 litre)


Sequential gearbox: Bleeding



#### **Equipment required**

Diagnostic tool

#### I - PROCEDURE



### WARNING

- Even a tiny air bubble can cause a malfunction.
- Incorrect bleeding may cause fault finding errors and lead to an unnecessary part replacement.

#### **II - GEARBOX REMOVED**

### WARNING

When removing the hydraulic clutch tappet, fill the tappet with an approved fluid (see 21B, Sequential gearbox, Sequential gearbox oil: Specifications, page 21B-82) before refitting the gearbox, following the procedure described below.

☐ Fill the reservoir (1) with approved clutch circuit fluid.

□ Activate the clutch tappet manually (releasing/engaging the clutch) until releasing/engaging the clutch becomes very difficult, without releasing any air bubbles. If necessary use the fluid (DOT4) to fill the reservoir.

#### **III - GEARBOX IN POSITION**

- ☐ Drain the reservoir of approved clutch circuit fluid.
- ☐ Remove the bleed screw cap.
- □ Connect a transparent tube to the bleed screw, connected to a syringe with an effective volume of 60 cm³ filled with approved fluid.
- ☐ Push the clutch pipe retaining clip and pull the pipe so that it is in the bleed position.
- □ Slowly inject the fluid in the syringe, making sure that the fluid does not overflow out of the reservoir.
- Carry out the Intake Reflux operations slowly using the syringe until all of the air bubbles have disappeared.

# **SEQUENTIAL GEARBOX Sequential gearbox: Bleeding**


21	В
----	---

Push the pipe back into the retaining clip.
 Perform an auto-bleed using the **Diagnostic tool**.
 Check that the system is operating correctly by carrying out a road test.
 The level is correct when the fluid is halfway up the reservoir.

Electro-hydraulic unit: List and location of components

21B

D4F, and JA3




1/9/3
-------

(1)	Clutch solenoid valve
(2)	Gear engagement solenoid valve
(3)	Gear engagement solenoid valve
<b>(4)</b>	Selection solenoid valve
<b>(5)</b>	Engagement sensor
(6)	Gear selection sensor
(7)	Solenoid valve unit pressure sensor
(8)	High pressure filter

Electro-hydraulic unit: List and location of components

21B

K9K, and JA5




1	79	79

(1)	Clutch solenoid valve
(2)	Gear engagement solenoid valve
(3)	Gear engagement solenoid valve
<b>(4</b> )	Selection solenoid valve
<b>(5)</b>	Engagement sensor
(6)	Gear selection sensor
(7)	Solenoid valve unit pressure sensor
(8)	High-pressure filter

23A

DP0



117304

The automatic transmission series number can be found in two places: on a label on the hydraulic distributor cover (1) and etched onto the outer casing (2) on the wheel side.

## Automatic gearbox oil: Draining - Filling



DP0

# **Equipment required** Diagnostic tool

Tightening torques ♡	
oil overflow pipe	9 N.m
level-setting plug	35 <b>N</b> .m
filler cap	35 N.m
mounting nuts on the scoop under the scuttle panel grille	6.5 N.m


#### I - OIL SERVICE

☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).

#### Note:

Drain the automatic transmission oil when the oil is warm (60°C maximum), in order to remove as many impurities as possible.

☐ Remove the engine undertray.



107912

- □ Remove:
  - the level-setting plug (1),
  - the oil overflow pipe (2) using an 8 mm Allen key **(3)** .
- ☐ Let the oil flow.

#### Note:

Always replace the overflow pipe (2) every time it is removed.


- ☐ Refit the new spillway.
- ☐ Torque tighten:
  - the oil overflow pipe (9 N.m),
  - the level-setting plug (35 N.m).

## Automatic gearbox oil: Draining - Filling


23A

DP0

#### **II - FILLING**



- ☐ Park the vehicle on level ground.
- ☐ It is essential to shift the selector lever to the Park position.
- ☐ Remove:
  - the scoop under the scuttle panel grille (see **Scoop** under the scuttle panel grille: Removal Refitting) (MR 393, 56A, Exterior equipment),
  - the air filter box (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - the battery tray (see **Battery tray: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove the filler cap (4).
- ☐ Use a funnel with a **15/100** filter to prevent any impurities from entering the system.
- ☐ Fill the gearbox with gearbox oil recommended by the manufacturer (see ) (Technical Note 6012, 04, Lubricants) using **3.5 litres** of new oil.
- ☐ Run the engine at idle speed.
- ☐ Connect the **Diagnostic tool**.
- ☐ Establish dialogue with the automatic gearbox computer.
- ☐ Monitor the gearbox oil temperature parameter.
- ☐ Wait for the temperature to reach 60°C ± 1.



- ☐ Place a container under the level-setting plug (5).
- □ Open the level-setting plug (5), leaving the engine running.
- ☐ If the oil does not flow out or the quantity collected is below **0.1 litres**:
  - Switch off the engine,
  - add **0.5 litre** of oil,
  - let the automatic transmission cool to 50°C,
  - run the engine at idle speed,
  - connect the Diagnostic tool,
  - establish dialogue with the automatic transmission computer,
  - monitor the gearbox oil temperature parameter,
  - wait for the temperature to reach 60°C,
  - place a container under the level-setting plug (5) .
- ☐ Repeat these operations until more than **0.1 litres** of oil is recovered in the container.
- □ Refit the level-setting plug (5).
- ☐ Torque tighten the filler cap (35 N.m).

#### III - LEVEL

☐ Park the vehicle on level ground.

#### Note:

The level must be checked according to the procedure described below.

Automatic gearbox oil: Draining - Filling

23A

P0
It is essential to shift the selector lever to the <b>Park</b> position.
Fill the automatic transmission with <b>0.5 litre</b> of new oil.
Run the engine at idle speed.
Connect the <b>Diagnostic tool</b> .
Establish dialogue with the automatic gearbox computer.
Monitor the gearbox oil temperature parameter.
Wait until the temperature reaches 60°C ± 1
Place a container under the level-setting plug,
open the level-setting plug.
If the oil does not flow or if the quantity collected is below <b>0.1 litres</b> :
- Switch off the engine,
- add <b>0.5 litre</b> of oil,
- let the automatic transmission cool to <b>50°C</b> ,
- run the engine at idle speed,
- connect the <b>Diagnostic tool</b> ,
- establish dialogue with the automatic transmission computer,
- monitor the gearbox oil temperature parameter,
- wait for the temperature to reach <b>60°C</b> ± <b>1</b> ,
- place a container under the level-setting plug,
- open the level-setting plug.
Repeat these operations until more than <b>0.1 litres</b> of oil is recovered in the container.
Note:
When the oil is replaced, the electronic oil ageing counter must be reset (inside the computer).
Refit:
- the air filter box (see <b>Air filter unit: Removal - Refitting</b> ) (MR 392, 12A, Fuel mixture),
-the scoop under the scuttle panel grille (see <b>Scoop</b> under the scuttle panel grille: Removal - Refitting) (MR 393, 56A, Exterior equipment).
Torque tighten the mounting nuts on the scoop under the scuttle panel grille (6.5 N.m).
Enter the date of the oil change using the <b>Diagnostic tool</b> (see <b>Fault finding - Configurations and programming)</b> (MR 394, 23A, Automatic transmission).

# AUTOMATIC GEARBOX Automatic gearbox: Specifications

23A

K4M, and 801, and DP0 – M4R, and 701, and DP0, and 021

Vehicle	Engine	Automatic trans- mission	Automatic trans- mission suffix	Reduction	Final drive
CROC BROC	M4R 701	DP0	021	52 / 67	21 / 73
CR0B BR0B	K4M 801	DP0	074	52 / 67	20 / 73

## Automatic gearbox converter: Fault finding

23A

DP0

#### **Equipment required**

#### Diagnostic tool

Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).

Lift the vehicle until the wheels are raised off the ground by a few centimetres.

Connect the Diagnostic tool.

Establish dialogue with the automatic transmission computer.

Monitor the automatic gearbox oil temperature parameter

Check that the oil temperature is between 60°C and 80°C.

Start the engine and shift the lever to D.

Monitor the engine speed parameter:

Establish dialogue with the computer.

Accelerate fully, keeping the brakes applied. The front wheels should not rotate.

#### WARNING

- Full load should not be maintained for more than **5 seconds**. Beyond this, there is a high risk of destroying the converter or the automatic gearbox.
- Once the measurement has been taken, release the accelerator and keep the brakes on until the engine speed stabilises to idle speed (there is a risk of damaging the automatic gearbox if this is not done).

The engine speed should stabilise at **2700 rpm**.

A setting point outside the tolerance requires the converter to be replaced.

#### Note:

A stall point which is too low may be linked to a lack of engine power.



K4M, and DP0

	Special tooling required
Mot. 1453	Engine anchorage support with multiple adjustments and retaining straps.


Equipment required
safety strap(s)
component jack
Diagnostic tool

Tightening torques ▽	
automatic transmission bell housing bolts	44 Nm
converter nuts	25 Nm
exhaust manifold bracket nuts	21 Nm
subframe bolt	105 Nm
automatic transmission connector bolts	20 Nm




#### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- ☐ Remove:
  - the engine undertray,
  - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
  - -the front wheel arch liners (see Front wheel arch liner: Removal Refitting) (55A, Exterior protection),
  - the battery (see ) (80A, Battery)
  - the battery tray (see ) (80A, Battery),
  - -the front bumper (see **Front bumper: Removal Refitting**) (55A, Exterior protection).




☐ Disconnect the modular connector by pulling the connector slide mechanism (1).

K4M, and DP0





- □ Remove:
  - the multifunction switch control cable by pressing at  $(\mathbf{A})$ ,
  - -the control cable sheath stop from the gearbox support by pulling the catch at (**B**) .
- ☐ Disconnect the crankshaft position sensor connector
- ☐ Remove the crankshaft position sensor.



- ☐ Disconnect the automatic transmission connector by pulling out the slide (2).
- □ Remove the bolts (3) from the automatic transmission connector and slide it into a waterproof plastic bag.

#### Note:


Protect the automatic transmission connector by sliding it into a waterproof plastic bag.

- ☐ Drain the cooling system (see Cooling system: Draining Refilling) (19A, Cooling).
- ☐ Disconnect the hoses from the expansion bottle.
- ☐ Remove the plastic rivet from the expansion bottle.

## Automatic gearbox: Removal - Refitting


23A

K4M, and DP0






- -the expansion bottle (4) in the direction of the arrow,
- the air resonator.
- □ Disconnect the automatic transmission cooling hoses.
- □ Remove the bottom cooling hose.
- ☐ Unclip the top cooling hose from the thermostat.
- □ Disconnect:
  - the engine cooling fan,
  - the engine fan relay unit,
  - the pressostat.
- ☐ Move the wiring aside.
- ☐ Unclip the radiator fan unit.
- Disconnect the anti-lock braking system sensor connectors.
- □ Remove:
  - -the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting, page 29A-2),
  - -the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).



- ☐ Remove the catalytic converter stay (5).
- ☐ Fit the cooling assembly to the upper cross member using a **safety strap(s)**.




#### Remove:

- the tie rod bolts (6),
- the side stiffener bolts (7),
- the bolts (8) on the cooling radiator support cross member.
- the cooling radiator support cross member,
- the fan unit.


## **Automatic gearbox: Removal - Refitting**

23A

K4M, and DP0




- ☐ Loosen the subframe bolt (9).
- ☐ Turn the stay (10) towards the rear to free the access to the automatic transmission.



- ☐ Remove:
  - the exhaust manifold bracket nuts (11),
  - the engine tie-bar (see Lower engine tie-bar: Removal Refitting) (19D, Engine mounting),
  - -the petrol injection computer (see **Petrol injection computer: Removal Refitting**) (17B, Petrol injection).



- ☐ Remove the wiring channel nuts (12) on the body.
- ☐ Attach the wiring channel in order to access the automatic transmission support freely.
- ☐ Remove the wiring channel nuts on the engine.




#### ☐ Remove:

- the bolt (13) on the automatic transmission earth strap,
- the starter (see Starter: Removal Refitting)
   (16A, Starting Charging),
- the converter nuts via the starter aperture.




K4M, and DP0

# II - OPERATION FOR REMOVAL OF PART CONCERNED




☐ Remove the upper automatic transmission bell housing stud (14).



☐ Fit the tool (Mot. 1453) with its safety strap(s).


#### □ Remove:

- -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (19D, Engine mounting),
- -the automatic transmission bell housing upper bolts.
- ☐ Fit the **component jack** beneath the automatic transmission.



#### ☐ Remove:

- the lower bolts (15) on the automatic transmission bell housing,
- the automatic transmission lower stud (16),
- the automatic gearbox.



☐ Attach the converter with string to stop it being detached.

### **Automatic gearbox: Removal - Refitting**




K4M, and DP0

#### REFITTING

#### I - REFITTING PREPARATION OPERATION


#### Note:

Do not reuse the converter nuts or the inertia flywheel nuts if they have been removed: always use new nuts.



110230

 $\ \ \square$  Check that the centring dowels (17) are in place.



□ Check the positioning of the converter in relation to the engine/automatic transmission coupling face using a ruler and a slide; the value should be (X) = 18.22 mm ± 1.

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit:
  - the automatic gearbox,
  - the automatic transmission studs,
  - the automatic transmission bell housing lower bolts.

#### Note:

Ensure that the converter is inserted correctly in the input shaft.

#### **III - FINAL OPERATION.**

- ☐ Remove the tool **component jack** under the automatic transmission.
- □ Refit the automatic transmission bell housing upper bolts
- ☐ Torque tighten the automatic transmission bell housing bolts (44 Nm).
- ☐ Refit the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (19D, Engine mounting).

## Automatic gearbox: Removal - Refitting

23A

K4M, and DP0		
☐ Remove the tool (Mot. 1453) with its safety	- the engine cooling fan.	
strap(s).	☐ Fit the thermostat upper cooling hose.	
☐ Refit the converter nuts via the starter aperture.	☐ Refit the lower cooling hose.	
☐ Torque tighten the converter nuts (25 Nm)	☐ Connect the automatic transmission cooling hoses.	
☐ Refit:	☐ Refit:	
<ul> <li>-the starter (see Starter: Removal - Refitting)</li> <li>(16A, Starting - Charging),</li> </ul>	- the air resonator,	
- the earth strap bolt on the automatic transmission.	- the expansion bottle,	
☐ Detach the wiring channel.	- the plastic rivet of the expansion bottle,	
☐ Refit:	- the front bumper (see Front bumper: Removal -	
- the nuts mounting the wiring channel to the body,	Refitting) (55A, Exterior protection).	
- the petrol injection computer (see Petrol injection	☐ Connect the expansion bottle hoses.	
computer: Removal - Refitting) (17B, Petrol injection),	☐ Fill the cooling system (see Cooling system: Draining - Refilling) (19A, Cooling).	
<ul> <li>- the engine tie-bar (see Lower engine tie-bar: Removal - Refitting) (19D, Engine mounting),</li> </ul>	Take the automatic transmission connector out of the plastic bag.	
- the exhaust manifold bracket.	☐ Refit the automatic transmission connector.	
☐ Torque tighten the exhaust manifold bracket nuts (21 Nm).	☐ Torque tighten the automatic transmission connector bolts (20 Nm).	
☐ Refit the subframe tie-rod.	☐ Connect the automatic transmission connector by	
☐ Torque tighten the <b>subframe bolt (105 Nm)</b> .	pushing the slide mechanism.	
□ Refit:	☐ Refit the crankshaft position sensor.	
- the fan assembly via the underbody of the vehicle,	☐ Connect the crankshaft position sensor.	
- the radiator support cross member,	☐ Refit:	
- the radiator support cross member bolts,	- the control cable sheath stop on the automatic	
- the side stiffener bolts,	transmission mounting,	
- the tie-rod bolts.	- the multifunction switch control cable.	
☐ Detach the cooling assembly from the upper cross member.	Connect the modular connector by pushing the connector slide mechanism.	
□ Refit:	☐ Refit:	
- the catalytic converter stay,	- the battery tray (see ) (80A, Battery),	
-the left-hand driveshaft (see 29A, Driveshafts,	- the battery (see ) (80A, Battery)	
Front left-hand driveshaft: Removal - Refitting, page 29A-2),	<ul> <li>the front wheel arch liners (see Front wheel arch liner: Removal - Refitting) (55A, Exterior protec- tion),</li> </ul>	
<ul> <li>-the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refit- ting, page 29A-9).</li> </ul>	- the front wheels (see <b>Wheel: Removal - Refitting</b> ) (35A, Wheels and tyres),	
☐ Connect the ABS sensor connectors.	- the engine undertray.	
☐ Clip on the radiator fan assembly.	☐ Connect the battery (see Battery: Removal - Refit-	
□ Connect:	ting) (80A, Battery).	
- the pressostat,	☐ Check the automatic transmission oil level (see 23A, Automatic gearbox, Automatic gearbox oil:	
- the engine fan relay unit,	Draining - Filling, page 23A-2).	

23A

K4M, and DP0

☐ If replacing the oil distributor, clear the auto-adaptive strategies using command RZ005 Clear auto-adaptive strategies and reset the oil ageing counter on the automatic transmission computer using the Diagnostic tool, run command CF074 « Write gearbox oil change date » .

After running command **RZ005**, it is essential to carry out a test drive performing all gear changes, both up and down, several times to store the new values.

23A

M4R, and 701, and DP0, and 021

Special tooling required	
Mot. 1672 Lower engine support.	


Equipment required		
component jack		

Tightening torques ♡	
automatic gearbox bell housing bolts	44 Nm
converter nuts	25 Nm
subframe bolt	105 Nm
converter nuts	25 Nm

#### REMOVAL


#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- □ Remove:
  - the engine cover,
  - the engine undertray.



114978

- ☐ Remove the air resonator on the battery following the direction of the arrows (A) then (B).
- ☐ Remove the battery (see **Battery: Removal Refitting**) (80A, Battery).



#### □ Remove:


- the modular connector (1),
- the air filter (see **Air filter: Removal Refitting**) (12A, Fuel mixture),
- the battery tray (see ) (80A, Battery).
- ☐ Drain the cooling system (see Cooling system: Draining Refilling) (19A, Cooling).


#### □ Remove:

- the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
- the front bumper (see Front bumper: Removal -Refitting) (55A, Exterior protection),
- the headlights (see ) (80B, Headlights) or (see Xenon headlight: Removal Refitting) (80C, Xenon bulbs),
- the frontal impact cross member (see Front impact cross member: Removal Refitting) (41A, Front lower structure),
- the front end panel (see **Front end panel: Remov- al Refitting**) (42A, Upper front structure),
- the cooling radiator (see Cooling radiator: Removal Refitting) (19A, Cooling).

23A


M4R, and 701, and DP0, and 021






#### □ Remove:

- the multifunction switch control (2),
- the multifunction switch sheath stop (3) .



#### □ Disconnect:

- the cooling hoses at (4) on the automatic gearbox,
- the automatic gearbox connector (5),
- the connector (6) from the automatic gearbox speed sensor,



#### ☐ Remove:

- the bolt (7) securing the automatic gearbox earth strap.
- the starter (see **Starter: Removal Refitting**) (16A, Starting Charging),




M4R, and 701, and DP0, and 021

- the converter nuts via the starter aperture.

#### □ Remove:

- the wiring channel mounting nuts on the body,
- the wiring channel mounting nuts on the engine.




110247

☐ Unscrew the nut (8) from the automatic gearbox upper stud.


#### ☐ Remove:

- -the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting, page 29A-2),
- -the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).



#### □ Remove:

- the side stiffener bolts (9),
- the side stiffener,
- the tie-rod bolt (10).




110240

- ☐ Loosen the subframe bolt (11).
- ☐ Move the tie rod (12) back to enable access to the automatic gearbox.
- □ Remove the radiator support cross member (see Radiator mounting cross member: Removal -Refitting) (41A, Front lower structure).

23A

M4R, and 701, and DP0, and 021




☐ Fit the tool (Mot. 1672) making sure that the support (13) is positioned as shown on the diagram.

#### □ Remove:

- -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (19D, Engine mounting),
- the automatic gearbox bell housing upper bolts.

# II - OPERATION FOR REMOVAL OF PART CONCERNED


☐ Fit the **component jack** beneath the automatic transmission.



#### □ Remove:

- the lower bolts (14) on the automatic gearbox bell housing,


- the automatic gearbox.



□ Attach the converter with string to stop it being detached.

#### REFITTING


#### I - REFITTING PREPARATION OPERATION



☐ Check that the centring dowels (15) are in place.

## **Automatic gearbox: Removal - Refitting**

M4R, and 701, and DP0, and 021



☐ Check the positioning of the converter in relation to the engine/automatic gearbox coupling face using a rule and a slide; the value should be at least (X) = 18.22 mm ± 1.

#### **II - REFITTING OPERATION FOR PART CONCERNED**

#### □ Refit:

- the automatic gearbox,
- the lower bolts on the automatic gearbox bell housing,
- the converter nuts via the starter aperture.

Ensure that the converter is perfectly inserted in the input shaft.


#### Note:

Do not reuse the converter nuts or the inertia flywheel nuts if they have been removed; always fit new nuts.

#### **III - FINAL OPERATION.**

- ☐ Remove the tool **component jack** under the automatic gearbox.
- ☐ Refit the automatic gearbox upper bolts.

- ☐ Tighten to torque:
  - the automatic gearbox bell housing bolts (44
  - the converter nuts (25 Nm).
- ☐ Refit the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (19D, Engine mounting).
- ☐ Remove the (Mot. 1672).
- ☐ Refit the radiator support cross member (see Radiator mounting cross member: Removal - Refitting) (41A, Front lower structure).



110240

- ☐ Fit the tie-rod (16).
- □ Refit the tie-rod bolt at (17).
- ☐ Torque tighten the subframe bolt (105 Nm) (18).
- □ Refit:
  - the side stiffener,
  - the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2),
  - the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9),
  - the wiring channel mounting nuts on the body,
  - the wiring channel mounting nuts on the engine.
- ☐ Torque tighten the **converter nuts (25 Nm)**.

23A

M4R, and 701, and DP0, and 021

#### □ Refit:


- -the starter (see **Starter: Removal Refitting**) (16A, Starting Charging),
- the earth strap on the automatic gearbox,
- the automatic gearbox earth strap bolt.

#### ☐ Connect:

- the automatic gearbox connector,
- the automatic gearbox speed sensor connector,
- the cooling hoses on the automatic gearbox.

#### □ Refit:

- the multifunction switch sheath stop,
- the multifunction switch control,
- the cooling radiator (see Cooling radiator: Removal Refitting) (19A, Cooling),
- the front end panel (see Front end panel: Removal Refitting) (42A, Upper front structure),
- -the frontal impact cross member (see Front impact cross member: Removal Refitting) (41A, Front lower structure),
- -the headlights (see ) (80B, Headlights) or (see **Xenon headlight: Removal Refitting**) (80C, Xenon bulbs),
- -the front bumper (see Front bumper: Removal Refitting) (55A, Exterior protection),
- the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
- the battery tray (see ) (80A, Battery),
- -the air filter (see **Air filter: Removal Refitting**) (12A, Fuel mixture),
- the modular connector,
- -the battery (see **Battery: Removal Refitting**) (80A, Battery).



- □ Push the air resonator towards the rear of the vehicle so that the corner of the air resonator is between the two lines marked on the air inlet hose.
- ☐ Press on the air resonator to fit it onto the battery cover.
- ☐ Perform the following operations:
  - fill the cooling system (see **Cooling system: Draining Refilling**) (19A, Cooling),
  - bleed the cooling system (see ) (19A, Cooling).

#### Refit:

- the engine cover,
- the engine undertray.

**Drive plate: Removal - Refitting** 



K4M, and DP0

Special tooling required		
Mot. 582-01	Flywheel locking tool.	
Carrie manut no muino d		

Equipment required

Diagnostic tool


Tightening torques ▽	
drive plate bolts	55 Nm + 50° ± 5

#### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

□ Remove the gearbox (see 23A, Automatic gearbox, Automatic gearbox: Removal - Refitting, page 23A-7).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



- ☐ Set up the (Mot. 582-01) (2) .
- ☐ Remove:
  - the bolts (2),
  - the drive plate,
  - tool (Mot. 582-01).

#### REFITTING

#### I - REFITTING PREPARATIONS OPERATION

☐ Check that the drive plate is not damaged (run-out tolerance of **0.2 mm** on the outer diameter).

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the drive plate, ensuring it is correctly positioned in relation to the centring pins.
- ☐ Apply **LOCTITE FRENBLOC** to the bolt threads.
- ☐ Tighten the bolts on the drive plate.
- ☐ Torque and angle tighten the **drive plate bolts (55** Nm + 50° ± 5) by immobilising the starter ring using the (Mot. 582-01).

#### **III - FINAL OPERATION.**

- □ Refit the gearbox (see 23A, Automatic gearbox, Automatic gearbox: Removal Refitting, page 23A-7).
- ☐ Connect the **Diagnostic tool** for the conformity check.

**Drive plate: Removal - Refitting** 

23A

M4R, and DP0

Special tooling required		
Mot. 919-02	Flywheel locking tool.	

Tightening torques	
drive plate bolts	108 Nm

#### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).

#### **IMPORTANT**

During this operation, secure the vehicle to the lift with a strap to prevent it from becoming unbalanced.

#### □ Remove:


- -the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery),
- the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),
- -the battery tray (see ) (MR 392, 80A, Battery),
- ☐ Drain the cooling system (see Cooling system: Draining Refilling) (MR 392, 19A, Cooling).

#### □ Remove:

- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
- -the front bumper (see Front bumper: Removal Refitting) (MR 393, 55A, Exterior protection),
- the headlights (see ) (MR 392, 80B, Headlights) or (see **Xenon headlight: Removal Refitting**) (MR 392, 80C, Xenon bulbs),
- -the frontal impact cross member (see Front impact cross member: Removal Refitting) (MR 393, 41A, Front lower structure),
- the front end panel (see **Front end panel: Removal Refitting**) (MR 393, 42A, Upper front structure),
- the cooling radiator (see Cooling radiator: Removal Refitting) (MR 392, 19A, Cooling),
- -the starter (see **Starter: Removal Refitting**) (MR392, 16A, Starting-charging),

- the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2),
- the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9)
- the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure),
- the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal - Refitting) (MR 392, 19D, Engine mounting),
- the automatic gearbox (see 23A, Automatic gearbox, Automatic gearbox: Removal - Refitting, page 23A-7).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



116747

- ☐ Set up the (Mot. 919-02) (1).
- □ Remove:
  - the drive plate mounting bolts (2),
  - the drive plate,
  - the (Mot. 919-02).

**Drive plate: Removal - Refitting** 

23A

M4R, and DP0

#### REFITTING

#### I - REFITTING PREPARATIONS OPERATION

☐ Check that the drive plate is not damaged (run-out tolerance of **0.2 mm** on the outer diameter).

## II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the drive plate, ensuring it is correctly positioned in relation to the centring pins.
- ☐ Apply **HIGH RESISTANCE THREAD LOCK** to the bolt threads.
- ☐ Finger tighten the drive plate mounting bolts.
- ☐ Torque and angle tighten the **drive plate bolts (108 Nm)** by immobilising the starter ring with the tool.

#### **III - FINAL OPERATION.**

#### □ Refit:

- the automatic gearbox (see 23A, Automatic gearbox, Automatic gearbox: Removal Refitting, page 23A-7),
- -the left-hand suspended engine mounting (see Left-hand suspended engine mounting: Removal Refitting) (MR 392, 19D, Engine mounting),
- -the radiator mounting cross member (see Radiator mounting cross member: Removal - Refitting) (MR 393, 41A, Front lower structure),
- -the right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9),
- -the left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting, page 29A-2),
- -the starter (see **Starter: Removal Refitting**) (MR392, 16A, Starting-charging),
- -the cooling radiator (see **Cooling radiator: Removal Refitting**) (MR 392, 19A, Cooling),
- -the front end panel (see Front end panel: Removal Refitting) (MR 393, 42A, Upper front structure),
- -the frontal impact cross member (see Front impact cross member: Removal Refitting) (MR 393, 41A, Front lower structure),
- the headlights (see ) (MR 392, 80B, Headlights) or (see **Xenon headlight: Removal Refitting**) (MR 392, 80C, Xenon bulbs),

- the front bumper (see Front bumper: Removal Refitting) (MR 393, 55A, Exterior protection),
- the front wheels (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres).
- ☐ Fill the cooling system (see Cooling system: Draining Refilling) (MR 392, 19A, Cooling).

#### □ Refit:

- the battery tray (see ) (MR 392, 80A, Battery),
- the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),
- the battery (see Battery: Removal Refitting)
   (MR 392, 80A, Battery).
- ☐ Bleed the cooling system (see ) (MR 392, 19A, Cooling).

# AUTOMATIC GEARBOX Multifunction switch: Removal - Refitting


DP0

	Tightening torques ♡	
gearbox mounting	connector bolts	20 Nm


#### REMOVAL


#### I - REMOVAL PREPARATION OPERATION

- ☐ Shift the selector lever to **Neutral**.
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove
  - the battery tray (see ) (MR 392, 80A, Battery),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).



- □ Pull the wiring connector lock (1).
- ☐ Disconnect the modular connector (2).






- ☐ Uncouple the automatic transmission control linkage by pressing (A) .
- ☐ Pull the control cable sleeve stop lock (B) .
- ☐ Move the control cable away from its support.

## Multifunction switch: Removal - Refitting


23A

DP0




- □ Pull the wiring connector lock (3).
- ☐ Disconnect the vehicle wiring.
- ☐ Remove the gearbox connector mounting bolts (4) from the support plate.





☐ Remove the green connector (6) from the gearbox connector (12 track).




#### □ Remove:

- the automatic transmission control cable support mounting bolts (7),
- the automatic transmission control cable support  $(\mathbf{8})$  .
- ☐ Detach the multifunction switch harness from the automatic transmission wiring neck.
- ☐ Mark the position of the automatic transmission control linkage.

# Multifunction switch: Removal - Refitting

23A

DP0



#### Remove:

- the automatic transmission control linkage (9),
- the multifunction switch mounting bolts (10),
- the multifunction switch (11).

### REFITTING

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the multifunction switch into the **Neutral position**.
- ☐ Finger tighten the multifunction switch mounting bolts until contact.
- ☐ Refit the automatic transmission control linkage.
- □ Adjust the multifunction switch (see 23A, Automatic transmission, Multifunction switch: Adjustment).
- ☐ Refit:
  - the automatic transmission control cable support,
  - -the automatic transmission control cable support mounting bolt.
- ☐ Fit the green connector into the gearbox connector (12-track).

#### **II - FINAL OPERATION**

- ☐ Refit the gearbox connector mounting board mounting bolts.
- ☐ Torque tighten the gearbox connector mounting bolts (20 Nm).
- Connect the automatic transmission wiring connector.
- ☐ Push the gearbox connector lock.
- ☐ Fit the automatic transmission control cable onto the mounting sheath stop.
- ☐ Push the control cable sheath stop lock.
- ☐ Connect the modular connector.
- ☐ Push the modular connector lock.
- □ refit:
  - the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),
  - the battery tray (see ) (MR 392, 80A, Battery).
- □ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).


**Multifunction switch: Adjustment** 

23A

DP0

Tightening torques ♡		
multifunction bolts	switch	10 N.m

### **ADJUSTMENT**



- ☐ Put the multifunction switch into the Neutral position.
- ☐ Place the test probes of an ohmmeter on the multifunction switch position check tabs.
- $\Box$  Turn the multifunction switch by hand until the electric contact is closed (resistance at contact terminals to be measured **0**  $\Omega$  with a tolerance of **60**  $\Omega$ )
- ☐ Torque tighten the multifunction switch bolts (10 N.m).
- $\Box$  Check that the resistance at the contact terminals is still **0**  $\Omega$  with a tolerance of **60**  $\Omega$  after tightening.
- ☐ Check that the system and gear selection are working correctly.

# AUTOMATIC GEARBOX Speed sensor: Removal - Refitting

23A

DP0

Tightening torques	
speed sensor mounting bolt	10 Nm
gearbox connector mounting bolts	20 Nm


Do not drain or remove the automatic gearbox in order to remove the speed sensor.

The output speed sensor has been deleted and replaced with wheel speed sensors.

#### REMOVAL


### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see ) (MR 392, 80A, Battery).
- Remove:
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection,
  - -the battery tray (see ) (MR 392, 80A, Battery),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).



☐ Disconnect the modular connector (1) by pulling the sliding latch (2).


# II - REMOVAL OPERATION FOR THE PART CONCERNED




- ☐ Disconnect the gearbox connector (3) by pulling the sliding latch (4).
- ☐ Remove the gearbox connector mounting bolts (5) from the support plate.


# **Speed sensor: Removal - Refitting**

DP0



- ☐ Extract the yellow connector (3-track) (6) from the gearbox connector.
- ☐ Release the speed sensor wiring harness from the automatic transmission wiring duct.





110239

- ☐ Remove:
  - the speed sensor mounting bolt,
  - the speed sensor (7) .

### **WARNING**

Protect the connector by sliding it into a water-proof plastic bag.

### **REFITTING**


# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the speed sensor.
- ☐ Torque tighten the speed sensor mounting bolt (10 Nm)).

# AUTOMATIC GEARBOX Speed sensor: Removal - Refitting

23A

DP0



# AUTOMATIC GEARBOX Pressure sensor: Removal - Refitting

23A


DP0

Tightening torques ♡	
pressure sensor mounting bolts	8 N.m
pressure sensor wiring harness mounting bolts	8 N.m
gearbox connector mounting bolts	20 N.m


### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on the two-post lift (see 02A, Lifting equipment, Vehicle: Towing and lifting).
- ☐ Disconnect the battery (see 80A, Battery, Battery: Removal Refitting).
- □ Remove:
  - the front left-hand wheel (see **35A**, **Wheels and ty-res**, **Wheel: Removal Refitting**),
  - -the front left-hand wheel arch liner (see MR Bodywork, 55A, Exterior protection, Wheel arch liner: Removal Refitting),
  - the engine undertray.
- □ Remove:
  - -the battery tray (see 80, Battery, Battery tray: Removal Refitting),
  - the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal Refitting).




☐ Disconnect the modular connector (1) by pulling the sliding (2).



- ☐ Disconnect the gearbox connector from the mounting plate by pulling the slide (3).
- ☐ Remove the gearbox connector mounting bolts (4) from the plate.


### Pressure sensor: Removal - Refitting

DP0



- ☐ Remove the green connector (3-track) (5) from the gearbox connector on the mounting plate.
- ☐ Release the pressure sensor wiring harness from the automatic transmission wiring duct.

# II - OPERATION FOR REMOVAL OF PART CONCERNED



110251

#### □ Remove:

- the wiring harness mounting bolt (6),
- the pressure sensor mounting bolts (7),
- the pressure sensor (8) .

### **WARNING**

Protect the connector by sliding it into a water-proof plastic bag.

### **REFITTING**

# I - REFITTING OPERATION FOR PART CONCERNED

### □ Refit:

- the pressure sensor,
- the pressure sensor mounting bolts,
- the wiring harness mounting bolt.


### ☐ Tighten to torque:

- the pressure sensor mounting bolts (8 N.m),
- the pressure sensor wiring harness mounting bolts (8 N.m).
- ☐ Connect the pressure sensor harness from the automatic transmission wiring duct.

# AUTOMATIC GEARBOX Pressure sensor: Removal - Refitting

23A

DP0



# AUTOMATIC GEARBOX Hydraulic distributor: Removal - Refitting



DP0

Special tooling required	
Bvi. 1462	Locating ball spring adjust- ment bolt.

### **Equipment required**


Diagnostic tool

Tightening torques ♡	
distributor mounting bolts	7.5 Nm
locating ball spring bracket mounting bolt	9 Nm
locating ball spring mounting bolt	8 Nm
cover mounting bolts 10 N	
reinforcement plate mounting bolts	21 Nm

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- ☐ Shift the selector lever to **Neutral**.
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- □ Remove:
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection),
  - the engine undertray.
- □ Drain the automatic transmission (see 23A, Automatic gearbox, Automatic gearbox oil: Draining Filling, page 23A-2) (MR 392, 23A, Automatic transmission).
- ☐ Remove:
  - the battery tray (see ) (MR 392, 80A, Battery),
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture).




☐ Disconnect the modular connector by pulling the sliding latch (1).

# Hydraulic distributor: Removal - Refitting

DP0






☐ Remove:

- -the multifunction switch control cable by pressing at  $(\mathbf{A})$  .
- the control cable sleeve stop from the gearbox support by pulling the catch at  $(\mathbf{B})$  .
- ☐ Drain the cooling system (see Cooling system: Draining Refilling) (MR 392, 19A, Cooling).
- ☐ Remove the expansion bottle hose at the radiator end
- □ Remove the front bumper (see Front bumper: Removal Refitting) (MR 393, 55A, Exterior protections)

tion).

☐ Remove the plastic rivet of the expansion bottle.




□ Remove:

- the expansion bottle (2) in the direction of the arrow,
- the resonator.
- ☐ Remove:
  - the cooling hoses at the automatic transmission side,
  - the bottom cooling hose, to provide free access to the radiator.
  - the fan assembly (see **Engine cooling fan assembly: Removal Refitting**) (MR 392, 19A, Cooling).
- ☐ Attach the radiator to the upper cross member.

# Hydraulic distributor: Removal - Refitting


23A

DP0




- □ Remove:
  - the tie-rod mounting bolts (3),
  - the mounting bolts (4) of the side stiffener,
  - the radiator mounting lower cross member mounting bolts  $(\mathbf{5})$  ,
  - the lower radiator cross member.





☐ Remove the hydraulic distributor cover mounting bolts (6) (oil may flow out).




- ☐ Remove the hydraulic distributor mounting bolts (7).
- ☐ Disconnect the hydraulic distributor solenoid valve connectors (8).

23A


DP0

### **REFITTING**

# I - REFITTING OPERATION FOR PART CONCERNED



13789



☐ Fit the distributor with its protection plate, centring it using the bolts (4) and (5).

### **WARNING**

Check that the distributor slide is properly engaged with the notched sector lug (9).


- ☐ Refit the other bolts on the distributor.
- ☐ Tighten to torque and in order the distributor mounting bolts (7.5 Nm).


# Hydraulic distributor: Removal - Refitting

23A

DP0

#### ADJUSTING THE LEAF SPRING LEVER





- ☐ Hold the multifunction switch lever in the end position (first selected) using a hose clip and a bolt (13) in the mechanism housing.
- □ Remove the bolt (14).
- ☐ Fit the locating ball spring by fitting the bearing (10) into the groove (11) for the notched sector (12) corresponding to first selected.
- ☐ Fit the locating ball spring bracket mounting bolt (15) without tightening it.
- ☐ Fit the (Bvi. 1462) (16) in place of the bolt (14).
- ☐ Screw the tool in fully whilst holding the locating ball spring.
- ☐ Torque tighten the locating ball spring bracket mounting bolt (9 Nm) (15).
- ☐ Remove the (Bvi. 1462).

- □ Refit the locating ball spring mounting bolt (14).
- ☐ Torque tighten the locating ball spring mounting bolt (8 Nm).
- ☐ Remove the hose clip and the bolt (13).
- ☐ If the oil distributor is replaced, the auto-adapatives must be reset to zero using command RZ005 « Clear auto-adaptives» and reset the oil age counter on the automatic transmission computer using the Diagnostic tool, run command CF074 « Enter date of gearbox oil change » .

After running command **RZ005**, it is essential to carry out a test drive performing all gear changes, both up and down, several times to store the new values.

- ☐ Torque tighten:
  - the cover mounting bolts (10 Nm),
  - the reinforcement plate mounting bolts (21 Nm).

# AUTOMATIC GEARBOX Hydraulic distributor: Removal - Refitting

23A

DP0



#### □ Refit:

- the radiator lower cross member,
- the side reinforcement,
- the tie-rod,
- the fan assembly (see **Engine cooling fan assembly: Removal Refitting**) (MR 392, 19A, Cooling),
- the bottom cooling hose,
- -the cooling hoses at the automatic transmission side,
- the resonator,
- the expansion bottle,
- a new expansion bottle plastic attachment rivet,
- the expansion bottle hose,
- the multifunction switch control cable.
- Connect the modular connector.
- □ Refit:
  - the air filter unit (see **Air filter unit: Removal Refitting**) (MR 392, 12A, Fuel mixture),
  - -the battery tray (see ) (MR 392, 80A, Battery),
- ☐ Fill the automatic transmission (see 23A, Automatic gearbox, Automatic gearbox oil: Draining Filling, page 23A-2) (MR 392, 23A, Automatic transmission).
- ☐ Refit:
  - the engine undertray,
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection),
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres).
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

# Flow control solenoid valve: Removal - Refitting



DP0


Tightening torques ▽	
heat exchanger flow control solenoid valve mounting bolt	10 Nm

Do not drain or remove the automatic gearbox in order to remove the flow control solenoid valve

### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

- ☐ Place the vehicle on a two-post lift (see **02A**, **Lifting** equipment, Vehicle: Towing and lifting).
- ☐ Disconnect the battery (see 80A, Battery, Battery: Removal - Refitting).
- □ Remove:
  - the front left-hand wheel (see 35A, Wheels and tyres, Wheel: Removal - Refitting).
  - -the front left-hand wheel arch liner (see MR 393, Bodywork, 55A, Exterior Protection, Wheel arch liner: Removal - Refitting).
  - -the battery tray (see 80A, Battery, Battery tray: Removal - Refitting).
  - the air filter unit (see 12A, Fuel mixture, Air filter unit), Removal - Refitting).



☐ Disconnect the modular connector (1) by pulling the connector sliding latch (2).

### **II - OPERATION FOR REMOVAL OF PART** CONCERNED





- ☐ Disconnect the flow control solenoid valve connector
- ☐ Unclip the flow control solenoid valve connector (3) from the gearbox connector support.
- ☐ Release the flow control solenoid valve wiring harness from the automatic transmission wiring duct.

### Flow control solenoid valve: Removal - Refitting

23A

DP0





- □ Remove:
  - the solenoid valve mounting bolts (4),
  - the heat exchanger flow control solenoid valve (5).

### REFITTING

# I - REFITTING OPERATION FOR PART CONCERNED

☐ Refit the heat exchanger flow control solenoid valve.

- ☐ Tighten to torque the heat exchanger flow control solenoid valve mounting bolt (10 Nm).
- ☐ Clip the flow control solenoid valve connector to the gearbox connector support.
- ☐ Connect the flow control solenoid valve connector.

### **II - FINAL OPERATION**

- ☐ Connect the modular connector by pushing the sliding latch.
- ☐ Refit:
  - the air filter unit (see 12A, Fuel mixture, Air filter unit), Removal - Refitting).
  - the battery tray (see 80A, Battery, Battery tray: Removal Refitting).
  - the front left-hand wheel arch liner (see MR 393, Bodywork, 55A, Exterior Protection, Wheel arch liner: Removal - Refitting).
  - the front left-hand wheel (see **35A**, **Wheels and ty-res**, **Wheel: Removal Refitting**).
- ☐ Connect the battery (see **80A**, **Battery**, **Battery**: **Removal Refitting**).
- ☐ Check the gearbox oil level (see 23A, Gearbox oil: Draining Filling).

### Hydraulic distributor solenoid valves: Removal - Refitting

DP0

#### **WARNING**


Work as cleanly as possible to prevent foreign bodies from entering the system.

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

☐ Remove the hydraulic distributor (see 23A, Automatic gearbox, Hydraulic distributor: Removal -Refitting, page 23A-34).

### **II - OPERATION FOR REMOVAL OF PART CONCERNED**



(1)	Modulating solenoid valve
(2)	« Lock up » solenoid valve (lockup converter)
(3)	Sequence solenoid valve 4
<b>(4)</b>	Sequence solenoid valve 3
<b>(5)</b>	Sequence solenoid valve 1
(6)	Sequence solenoid valve 2
<b>(7</b> )	Sequence solenoid valve 6
(8)	Sequence solenoid valve 5

☐ Remove the hydraulic distributor solenoid valves.

### REFITTING

### I - REFITTING OPERATION FOR PART **CONCERNED**

☐ Refit the hydraulic distributor solenoid valves.

### **II - FINAL OPERATION**

☐ Refit the hydraulic distributor (see 23A, Automatic gearbox, Hydraulic distributor: Removal - Refitting, page 23A-34).

# Automatic gearbox connector: Removal - Refitting




DP0

Tightening torques ♡	
gearbox support	10 Nm
gearbox connector	20 Nm


### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Shift the selector lever to **Neutral**.
- □ Disconnect the battery (see ) (MR 392, 80A, Battery).
- □ Remove:
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres),
  - -the front left-hand wheel arch liner (see **Front wheel arch liner: Removal Refitting**) (MR 393, 55A, Exterior protection,
  - the engine undertray,
  - the battery tray (see ) (MR 392, 80A, Battery),
  - the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture).




☐ Disconnect the modular connector (1) by pulling the sliding latch (2).



#### □ Remove:

- the multifunction switch control cable by pressing at  $(\mathbf{A})$  ,
- the control cable sleeve stop from the gearbox support by pulling the catch at (**B**) .

# II - OPERATION FOR REMOVAL OF PART CONCERNED




- ☐ Disconnect the gearbox connector (3) by pulling the sliding latch (4).
- ☐ Remove the gearbox connector mounting bolts (5).

# Automatic gearbox connector: Removal - Refitting




DP0



□ Remove:

- the gearbox connector support mounting bolts (6),
- the gearbox connector support (7).
- the coloured connector concerned on the gearbox connector.
- ☐ Follow the five wiring harnesses connected to the gearbox connector.



13785

(8)	Green connector (multifunction switch)
(9)	Yellow connector (electronic interface)
<b>(10</b> )	Green connector (line pressure)
<b>(11)</b>	Yellow connector (turbo speed)
(12)	Blue connector (exchanger flow control solenoid valve)

☐ Remove the five harnesses (these connectors can be removed separately from the gearbox connector when replacing certain components).

#### REFITTING

### I - REFITTING OPERATION FOR PART **CONCERNED**

- ☐ Connect the five harnesses to the gearbox connec-
- ☐ Refit the gearbox mounting.
- ☐ Torque tighten:
  - the gearbox support (10 Nm),
  - the gearbox connector (20 Nm).
- □ Connect the gearbox connector by pushing in the slide.
- ☐ Fasten the multifunction switch control cable.

### **II - FINAL OPERATION**

- ☐ Refit:
  - the air filter unit (see Air filter unit: Removal Refitting) (MR 392, 12A, Fuel mixture),
  - the battery tray (see ) (MR 392, 80A, Battery).
- □ Connect:
  - the modular connector reinserting the sliding latch,
  - the battery (see ) (MR 392, 80A, Battery).
- □ Refit:
  - the front left-hand wheel arch liner (see Front wheel arch liner: Removal - Refitting) (MR 393, 55A, Exterior protection,
  - the engine undertray,
  - the front left-hand wheel (see Wheel: Removal -Refitting) (MR 392, 35A, Wheels and tyres).

# Automatic gearbox converter: Removal - Refitting

23A


DP0

### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- ☐ Remove the front left-hand wheel arch liner (see Front wheel arch liner: Removal Refitting) (MR 393, 55A, Exterior protection).
- ☐ Remove the resonator on the battery.
- □ Disconnect the battery (see ) (MR 392, 80A, Battery).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



- 110689
- ☐ Disconnect the automatic transmission computer connector by pulling out the slide (1).
- ☐ Unfasten the automatic transmission computer retaining strap.
- ☐ Remove the automatic transmission computer.

### If replacing the automatic transmission computer

- □ Determine the oil age value using parameter PR133« Oil age counter » and make a note of the value.
- □ Copy the value into the memory of the new computer using command CF320 « Oil age counter transfer » .
- ☐ Confirm the entry using parameter «Oil age counter».
- ☐ Enter the After Sales operation date using command CF320 « Enter After-Sales operation date » .
- ☐ Carry out a road test so that the new computer stores the programming.

### REFITTING

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the computer.
- ☐ Fasten the automatic transmission computer retaining strap.
- ☐ Connect the automatic transmission computer connector by pushing in the slide.

#### II - FINAL OPERATION.

- □ Refit the front left-hand wheel arch liner (see Front wheel arch liner: Removal Refitting) (MR 393, 55A, Exterior protection).
- ☐ Connect the battery (see ) (MR 392, 80A, Battery).

Differential seal: Removal - Refitting

23A

DP0

Special tooling required	
Bvi. 1459	Right-hand driveshaft outlet seal fitting tool.
Bvi. 1460	Left-hand driveshaft outlet seal fitting tool.

☐ Fill and check the gearbox oil level (see 23A, Automatic gearbox, automatic gearbox oil: Draining - Filling).

### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- □ Place the vehicle on a two-post lift (see **02A**, **Lifting equipment**, **Vehicle: Towing and lifting**).
- ☐ Remove the engine undertray.
- □ Remove the corresponding driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal Refitting).
- □ Drain the automatic gearbox (see 23A, Automatic gearbox, Automatic gearbox oil: Draining Filling).

# II - OPERATION FOR REMOVAL OF PART CONCERNED

☐ Remove the faulty differential output seal using a screwdriver or a hook, taking care not to scratch the contact faces.

#### **WARNING**

Do not drop the seal spring into the automatic transmission.

### REFITTING

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the seal using tool (Bvi. 1459) on the left-hand side or tool (Bvi. 1460) on the right-hand side.
- ☐ Guide the assembly until the tool is resting on the automatic gearbox casing.

#### **II - FINAL OPERATION**

□ Refit the corresponding driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting) or (see 29A, Driveshafts, Front lefthand driveshaft: Removal - Refitting).

# Converter seal: Removal - Refitting



DP0

Special tooling required	
Bvi. 1400-01	Tool kit for operations on Aisin Warner type automatic transmission.
Bvi. 1457	Converter lip seal fitting tool.

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

□ Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (MR 392, 02A, Lifting equipment).

#### **IMPORTANT**

During this operation, secure the vehicle to the lift with a strap to prevent it from becoming unbalanced.

- □ Remove the automatic transmission (see 23A, Automatic gearbox, Automatic gearbox: Removal Refitting, page 23A-7) (MR 392, 23A, Automatic transmission).
- ☐ Remove the converter by withdrawing it as far as possible without deviating from its axis.

### Note:

The converter contains a large amount of oil which could escape when it is being removed.

# II - OPERATION FOR REMOVAL OF PART CONCERNED

☐ Remove the seal, using the tool (Bvi. 1400-01), taking care not to scratch the contact surfaces.

### REFITTING


# I - REFITTING OPERATION FOR PART CONCERNED

☐ Refit the new pre-lubricated seal to the stop, using the (Bvi. 1457).

### **WARNING**

Work as cleanly as possible to prevent foreign bodies from entering the system.

Lubricate all the contact faces.



□ Check the positioning of the converter in relation to the engine/automatic transmission coupling face using a straightedge and a steel ruler; the value should be (X) = 18.22 mm ± 1.

### **II - FINAL OPERATION.**

□ Refit the automatic transmission (see 23A, Automatic gearbox, Automatic gearbox: Removal - Refitting, page 23A-7) (MR 392, 23A, Automatic transmission).

# DRIVESHAFTS Driveshaft: Precautions for the repair

29A

DP0 or JH3 or JR5 or TL4

### WARNING

A gearbox oil leak at the driveshaft may destroy it.

#### **WARNING**

Always replace seals whenever the driveshaft is removed.

### **WARNING**

Grease the base of the bearing using **BR 2 +** grease to prevent the bearing from sticking.

Make sure that the O-ring is correctly positioned in the base of the relay bearing, if the bearing has one.

### **WARNING**

Always replace the O-ring, if fitted to the bearing.

### **WARNING**

Always replace the relay bearing support plate.

### **WARNING**

Always replace the left-hand driveshaft locking spring ring, if the driveshaft has one.

### **WARNING**

In order to prevent irreversible damage to the front hub bearing:

- Do not loosen or tighten the driveshaft nut when the wheels are on the ground.
- Do not place the vehicle with its wheels on the ground when the driveshaft has been loosened or removed.

# Front left-hand driveshaft: Removal - Refitting



DP0 or JH3 or JR5 - K4M or K9K or M4R, and TL4

Special tooling required	
Rou. 604-01	Hub locking tool.
Tav. 476	Ball joint extractor.

Tightening torques	
hub nut	280 Nm
shock absorber base bolts	110 Nm
track rod end nut	37 Nm
anti-roll bar linkage upper ball joint nut	37 Nm
brake calliper support mounting bolts	105 Nm

### **REMOVAL**


### I - REMOVAL PREPARATION OPERATION


- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- ☐ Remove the engine undertray.
- □ Remove the front right-hand wheel (see Wheel: Removal Refitting) (MR 392, 35A, Wheels and tyres).

## Front left-hand driveshaft: Removal - Refitting



DP0 or JH3 or JR5 – K4M or K9K or M4R, and TL4





- ☐ Unclip the left-hand wheel speed sensor.
- □ Remove:
  - the hub nut (1), using the (Rou. 604-01),
  - the left-hand steering ball joint (4), using the (Tav. 476) at (5),
  - the left-hand upper ball joint of the anti-roll bar linkage (2),
  - the left-hand brake calliper support mounting bolts (see Front brake calliper mounting: Removal Refitting) (MR 392, 31A, Front axle components),
  - the left-hand shock absorber lower mounting bolts

**(3)** .

□ Attach the brake calliper to the shock absorber spring.

### **II - REMOVAL OF PART CONCERNED**


- ☐ Pivot the stub axle carrier to separate the driveshaft from the stub axle carrier.
- ☐ Remove the driveshaft from the gearbox.

### REFITTING

### I - REFITTING PART CONCERNED

- ☐ Insert the driveshaft splines into the differential grooves.
- ☐ Insert the drive shaft splines in the hub grooves.
- ☐ Fit the left-hand shock absorber lower mounting bolts.

### **II - FINAL OPERATION**



128087

112619

### Note:

If equipped with the 5<sup>th</sup>injector.

After carrying out the operation, check that the dimension between the driveshaft and the hose for the 5<sup>th</sup>injector is at least 25mm.

To avoid damaging the hose.

# Front left-hand driveshaft: Removal - Refitting



DP0 or JH3 or JR5 – K4M or K9K or M4R, and TL4

Fit:
- the left-hand track rod end,
- the left-hand upper ball joint of the anti-roll bar link-age,
- the left-hand brake calliper support mounting bolts (see <b>Front brake calliper mounting: Removal Refitting</b> ) (MR 392, 31A, Front axle components).
Tighten to torque:
-the hub nut (280 Nm), using the (Rou. 604-01),
-the shock absorber base bolts (110 Nm),
-the track rod end nut (37 Nm),
-the anti-roll bar linkage upper ball joint nut (37 Nm),
<ul> <li>-the brake calliper support mounting bolts (105 Nm) (see Front brake calliper mounting: Removal - Refitting) (MR 392, 31A, Front axle components).</li> </ul>
Refasten the clips on the wheel speed sensor.
Refit the engine undertray.

□ Refit the front left-hand wheel (see **Wheel: Removal** - **Refitting**) (MR 392, 35A, Wheels and tyres).

# Front left-hand driveshaft: Removal - Refitting



F4R, and TL4

Special tooling required		
Rou. 604-01	Hub locking tool.	
Tav. 1813	Extraction claw for clip secured type driveshafts	

Equipment required
safety strap(s)
component jack


Tightening torques ♡	
front shock absorber tur- ret bolts	21 N.m
front brake calliper bolts	170 N.m
track rod bolt	37 N.m
driveshaft nut	280 N.m

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (80A, Battery).
- □ Remove:
  - the engine undertray bolts,
  - the engine undertray,
  - the front left-hand wheel (see **Wheel: Removal Refitting**) (35A, Wheels and tyres).
- ☐ Drain the gearbox oil (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).

# II - OPERATION FOR REMOVAL OF PART CONCERNED



116760

- ☐ Remove the nut from the front left-hand driveshaft (1) using the tool (Rou. 604-01).
- ☐ Unclip the ABS sensor wiring harness (2).
- ☐ Remove the ABS sensor bolt (3).
- ☐ Move the ABS sensor to one side.




116761


- ☐ Remove:
  - the track rod nut (4),
  - the track rod.

# Front left-hand driveshaft: Removal - Refitting


F4R, and TL4




☐ Remove the bolt (5) from the clip on the front brake hose.



- ☐ Remove the front brake calliper bolts (6).
- Move the front brake calliper away and attach it using a safety strap(s) to the spring of the front shock absorber.



 $\ \square$  Remove the linkage nuts (7).




- ☐ Fit a **component jack** to compress the front suspension.
- ☐ Remove the linkage.
- ☐ Remove the **component jack**.
- ☐ Remove the scuttle panel grille (see Scuttle panel grille: Removal Refitting) (56A, Exterior equipment).

## Front left-hand driveshaft: Removal - Refitting




F4R, and TL4




#### Remove:

ret.

- the nut (8) from the cover of the front shock absorber turret,
- the cover of the front shock absorber turret.



□ Loosen the bolts (**9**) on the front shock absorber tur-



#### □ Remove:

- the hub carrier lower shaft bolt (10),
- the bolts (11) from the pivot support.
- ☐ Separate the spring shock absorber pivot assembly.

### ☐ Remove:

- the front left-hand driveshaft from the front lefthand wheel hub.
- the front left-hand driveshaft from the gearbox.
- ☐ Remove the front left-hand driveshaft using the tool (Tav. 1813) and.

### REFITTING

### I - REFITTING PREPARATION OPERATION

- □ Remove the left-hand side differential output seal (see 21A, Manual gearbox, Differential output seal: Removal Refitting, page 21A-46).
- □ Refit a new differential output seal on the left-hand side (see 21A, Manual gearbox, Differential output seal: Removal Refitting, page 21A-46).

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the front left-hand driveshaft by inserting it into the gearbox then into the front wheel hub.
- □ Refit:
  - the bolts of the pivot support,

# Front left-hand driveshaft: Removal - Refitting

29A

F4R, and TL4 - the hub carrier lower shaft bolt. ☐ Torque tighten the front shock absorber turret bolts (21 N.m). ☐ Fit a **component jack** to compress the front suspension. ☐ Refit the linkage. ☐ Remove the **component jack**. ☐ Refit the linkage nuts. ☐ Fit the front brake calliper. ☐ Torque tighten the front brake calliper bolts (170 ☐ Refit the bolt of the clip on the front brake calliper hose. Position the track rod. Refit the track rod nut. ☐ Torque tighten the track rod bolt (37 N.m). □ Refit: - the ABS sensor, -the ABS sensor bolt. ☐ Clip the ABS sensor wiring harness. ☐ Refit the driveshaft nut using the (Rou. 604-01). ☐ Torque tighten the driveshaft nut (280 N.m). **III - FINAL OPERATION** □ Refit: - the cover of the front shock absorber turret, - the nut for the cover of the front shock absorber tur--the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (56A, Exterior equipment), -the front left-hand wheel (see Wheel: Removal -**Refitting**) (35A, Wheels and tyres). ☐ Top up the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining - Filling, page 21A-3). ☐ Refit the engine undertray. ☐ Connect the battery (see Battery: Removal - Refit-

ting) (80A, Battery).

# Front right-hand driveshaft: Removal - Refitting



JH3 or JR5 – K4M or K9K or M4R, and TL4

Special tooling required	
Rou. 604-01	Hub locking tool.
Tav. 476	Ball joint extractor.

Tightening torques ♡	
driveshaft relay bearing bracket mounting bolts	21 Nm
hub nut	280 Nm
shock absorber base bolts	110 Nm
track rod end nut	37 Nm
anti-roll bar linkage upper ball joint nut	37 Nm
brake calliper support mounting bolts	105 Nm

### **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- ☐ Remove the engine undertray.
- ☐ Drain the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- □ Remove the front right-hand wheel (see Wheel: Removal Refitting) (MR392, 35A, Wheels and tyres).


# Front right-hand driveshaft: Removal - Refitting



JH3 or JR5 - K4M or K9K or M4R, and TL4




112049



- ☐ Unclip the right-hand wheel speed sensor.
- □ Remove:
  - the hub nut (1) using the (Rou. 604-01),
  - the anti-roll bar linkage right-hand upper ball joint (2) ,
  - -the right-hand track rod end (4), using the (Tav. 476) at (5),
  - -the right-hand brake calliper support mounting bolts (see Front brake calliper mounting: Removal - Refitting) (MR 392, 31A, Front axle components),

- the right-hand shock absorber lower mounting bolts (3).
- ☐ Attach the brake calliper to the shock absorber spring.

D4F, and 740 or 742, and JH3



108819

#### □ Remove:


- the driveshaft relay bearing bracket mounting bolts (6),
- the driveshaft relay bearing bracket.

# Front right-hand driveshaft: Removal - Refitting



JH3 or JR5 - K4M or K9K or M4R, and TL4


K4J, and 780, and JH3 – K4M, and 800, and JH3 – K9K, and 768, and JH3 – K9K, and 766, and JR5



109166

- □ Remove:
  - the driveshaft relay bearing bracket mounting bolts (7) ,
  - the driveshaft relay bearing bracket.

K9K, and 764, and TL4



- ☐ Remove the driveshaft relay bearing bracket mounting bolt (8).
- ☐ Pivot the driveshaft relay bearing bracket.

### **II - REMOVAL OF PART CONCERNED**

- ☐ Pivot the stub axle carrier to separate the driveshaft from the stub axle carrier.
- ☐ Remove the driveshaft from the gearbox.

### **REFITTING**

### I - REFITTING PREPARATION OPERATION

Check the condition of the lip seal mating face on the driveshaft.

### **WARNING**


Do not refit a driveshaft if the lip seal mating face is damaged.

☐ Replace the differential output lip seal (see 21A, Manual gearbox, Differential output seal: Removal - Refitting, page 21A-46).

# Front right-hand driveshaft: Removal - Refitting

29A

JH3 or JR5 - K4M or K9K or M4R, and TL4



# Front right-hand driveshaft: Removal - Refitting



DP0

Special tooling required	
Rou. 604-01	Hub locking tool.
Tav. 476	Ball joint extractor.

Tightening torques	
driveshaft relay bearing bracket mounting bolt	21 Nm
hub nut	280 Nm
shock absorber base bolts	110 Nm
track rod end nut	37 Nm
anti-roll bar linkage upper ball joint nut	37 Nm
brake calliper support mounting bolts	105 Nm

### **REFITTING**


### I - REMOVAL PREPARATION OPERATION


- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- ☐ Remove the engine undertray.
- □ Remove the front right-hand wheel (see Wheel: Removal Refitting) (MR 392, 35A, Wheels and tyres).

# Front right-hand driveshaft: Removal - Refitting



DP0





- ☐ Unclip the right-hand wheel speed sensor.
- □ Remove:
  - the hub nut (1) using the (Rou. 604-01),
  - the anti-roll bar linkage right-hand upper ball joint (2),
  - -the right-hand track rod end (4), using the (Tav. 476) at (5),
  - -the right-hand brake calliper support mounting bolts (see Front brake calliper mounting: Removal - Refitting) (MR 392, 31A, Front axle components),

- the right-hand shock absorber lower mounting bolts (3).
- □ Attach the brake calliper to the shock absorber spring.



□ Remove the driveshaft relay bearing bracket mounting bolt (6).

### **II - REMOVAL OF PART CONCERNED**

- ☐ Pivot the stub axle carrier to separate the driveshaft from the stub axle carrier.
- ☐ Remove the driveshaft from the gearbox.

### **REMOVAL**

### I - REFITTING PART CONCERNED

- ☐ Insert the driveshaft splines into the differential grooves.
- ☐ Insert the drive shaft splines in the hub grooves.
- ☐ Fit:

112619

- the right-hand shock absorber lower mounting bolts,
- the driveshaft relay bearing bracket.
- □ Refit the driveshaft relay bearing bracket mounting bolt (6).

#### **II - FINAL OPERATION**

- ☐ Fit:
  - the right-hand track rod end,

## Front right-hand driveshaft: Removal - Refitting

29A

## DP0

- the anti-roll bar linkage right-hand upper ball joint,
- -the right-hand brake calliper support mounting bolts (see **Front brake calliper mounting: Removal - Refitting**) (MR 392, 31A, Front axle components).
- ☐ Torque tighten:
  - -the driveshaft relay bearing bracket mounting bolt (21 Nm),
  - the hub nut (280 Nm), using the (Rou. 604-01),
  - -the shock absorber base bolts (110 Nm),
  - -the track rod end nut (37 Nm),
  - -the anti-roll bar linkage upper ball joint nut (37 Nm),
  - the brake calliper support mounting bolts (105 Nm) (see Front brake calliper mounting: Removal Refitting) (MR 392, 31A, Front axle components).
- ☐ Refasten the clips on the wheel speed sensor.
- ☐ Refit the engine undertray.
- ☐ Refit the front right-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres).

## Front right-hand driveshaft: Removal - Refitting



F4R, and TL4

Special tooling required	
Rou. 604-01	Hub locking tool.

# **Equipment required** component jack


Tightening torques ▽	
driveshaft relay bearing support plate mounting bolts	21 Nm
brake calliper mounting bolts	170 Nm
track rod mounting bolt	37 Nm
driveshaft nut	280 Nm

## **REMOVAL**


#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- □ Remove:
  - the engine undertray,
  - the front right-hand wheel (see Wheel: Removal -Refitting) (MR 392, 35A, Wheels and tyres).
- ☐ Drain the gearbox oil (see 21A, Manual gearbox, Manual gearbox oils: Draining - Filling, page 21A-3).

### **II - OPERATION FOR REMOVAL OF PART CONCERNED**



☐ Remove the driveshaft nut using the (Rou. 604-01).




- 116760
- ☐ Unclip the ABS sensor wiring harness (1).
- ☐ Remove the ABS sensor mounting bolt (2).
- ☐ Move the ABS sensor to one side.


## Front right-hand driveshaft: Removal - Refitting




F4R, and TL4




- ☐ Remove the track rod mounting nut (3).
- ☐ Remove the track rod.



☐ Remove the calliper hose mounting bolt (4).



- □ Remove the brake calliper mounting bolts (5) .
- □ Remove the brake calliper and strap it up (see Front brake calliper: Removal Refitting) (MR 392, 31A, Front axle components).




☐ Remove the linkage nuts (6).


## Front right-hand driveshaft: Removal - Refitting




F4R, and TL4




- ☐ Fit a **component jack** to compress the suspension.
- ☐ Remove the linkage.
- ☐ Remove the **component jack**.
- □ Remove the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 55A, Exterior protection).



- ☐ Remove:
  - the turret cover mounting nut (7),
  - the turret cover.



☐ Loosen the turret mounting bolts (8).




- ☐ Remove:
  - the hub carrier lower axis locking bolt (9),
  - the mounting bolts (10) from the pivot mounting.
- □ Remove the "spring shock absorber pivot" assembly.
- ☐ Extract the hub driveshaft.

## Front right-hand driveshaft: Removal - Refitting



F4R, and TL4



- 116808
- ☐ Remove the right-hand driveshaft relay bearing support plate mounting bolts (11).
- ☐ Extract the driveshaft from the gearbox.
- ☐ Remove the right-hand driveshaft.

### **REFITTING**

#### I - REFITTING PREPARATIONS OPERATION

☐ Replace the differential output seal (see 21A, Manual gearbox, Differential output seal: Removal - Refitting, page 21A-46).

#### **WARNING**

Always replace the differential output lip seal with a new one whenever the driveshafts are removed.

# II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the driveshaft by inserting it into the gearbox and then the hub carrier.
- ☐ Refit:
  - the driveshaft relay bearing support plate,
  - the driveshaft relay bearing support plate mounting bolts.
- ☐ Torque tighten the driveshaft relay bearing support plate mounting bolts (21 Nm)

□ Refit:
- the pivot mounting bolts,
- the hub carrier lower axis locking bolt.
☐ Fit a <b>component jack</b> to compress the suspension.
☐ Refit the linkage.
☐ Remove the <b>component jack</b> .
☐ Refit the linkage mounting bolts.
☐ Refit the brake calliper mounting bolts.
☐ Tighten to torque the brake calliper mounting bolts (170 Nm).
☐ Refit the calliper hose mounting bolt.
☐ Position the track rod.
☐ Refit the track rod mounting nut.
☐ Tighten to torque the <b>track rod mounting bolt (37 Nm)</b> .
☐ Refit the ABS sensor.
☐ Clip the ABS sensor wiring harness.

☐ Refit the driveshaft nut using the (Rou. 604-01).

☐ Tighten to torque the driveshaft nut (280 Nm)

### **III - FINAL OPERATION.**

- ☐ Refit:
  - the turret cover,
  - the turret cover mounting nut,
  - the scuttle panel grille (see Scuttle panel grille: Removal - Refitting) (MR 393, 55A, Exterior protection),
  - the front right-hand wheel (see **Wheel: Removal Refitting**) (MR 392, 35A, Wheels and tyres).
- ☐ Top up the gearbox (see 21A, Manual gearbox, Manual gearbox oils: Draining Filling, page 21A-3).
- ☐ Refit the engine undertray.
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

## Relay shaft bearing: Removal - Refitting



M4R, and TL4


### **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION

- ☐ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).
- ☐ Remove the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).

#### **II - REMOVAL OF PART CONCERNED**

Removing the relay shaft bearing



100642

- ☐ Remove the lock ring (7) from the bearing (8).
- Extract the bearing (8) using a press and an extractor.
- ☐ Take care not to scratch the contact surface of the lip seal on the relay shaft (9).

### REFITTING

#### I - REFITTING PART CONCERNED

- ☐ Lubricate the contact surface of the shaft into which the bearing is inserted.
- ☐ Insert the new bearing.
- ☐ Fit the bearing to the end using a tube, so that it rests on the inner bearing race.
- ☐ Fit a new lock ring.
- ☐ Clean and grease the bearing hole into which the bearing will be inserted.

#### II - FINAL OPERATION.

- □ Refit the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9).
- □ Connect the battery (see **Battery**: **Removal Refitting**) (MR 392, 80A, Battery).

## Front driveshaft gaiter, wheel side: Removal - Refitting



M4R, and TL4

Special tooling required	
Tav. 1796	Driveshaft bowl-shaped spin- dle extractors
Emb. 880	Pin extractor tool.
Tav. 1784	Pliers for the driveshaft gaiter collar.
Tav. 1168	"Clic" type clip pliers for drive- shafts with a thermoplastic gaiter.

### **REMOVAL**


### I - REMOVAL PREPARATION OPERATION

☐ Remove the driveshaft on the side concerned (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2) .


### **II - OPERATION FOR REMOVAL OF PART CONCERNED**



- ☐ Cut the clips taking care not to damage the groove of the stub axle bowl.
- ☐ Push back the gaiter to release the stub axle bowl.



☐ Remove the stub axle bowl (1) using the (Tav. 1796) (2) and the extractor (Emb. 880) (3).



#### □ Remove:

- the locking spring ring (4),
- the gaiter (5).
- ☐ Remove as much grease as possible from the stub axle bowl.


## Front driveshaft gaiter, wheel side: Removal - Refitting




M4R, and TL4

## REFITTING

## I - REFITTING OPERATION FOR PART **CONCERNED**




115196




115197


- ☐ Use:
  - -the (Tav. 1784) for the clip with profile end (6),
  - the (Tav. 1168) for the jubilee type clip (7).



- 109768
- ☐ Always replace the locking spring ring (8) each time the stub axle bowl is removed.
- ☐ Fit the small clip.
- ☐ Fit the gaiter.
- ☐ Fit the stub axle bowl manually until the locking spring ring clicks behind the ball hub.
- ☐ Spread the quantity of grease around the gaiter and the stub axle bowl.
- ☐ Insert the lips of the gaiter into the grooves of the stub axle bowl and propeller shaft.

M4R, and TL4





☐ Fit the clips, tightening them using the (Tav. 1784) (9) or the (Tav. 1168) (10) depending on the type of clip.

## II - FINAL OPERATION.

☐ Refit the driveshaft on the side concerned (see 29A, Driveshafts, Front right-hand driveshaft: Removal - Refitting, page 29A-9) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2).

## Front right-hand driveshaft gaiter, gearbox side: Removal - Refitting




DP0 or JH3 or JR5 or TL4

## Special tooling required

Tav. 1168

"Clic" type clip pliers for driveshafts with a thermoplastic gaiter.



(2) Propeller shaft

(3) Driveshaft yoke sleeve

(4) Spider

(5) RC gaiter

(6) Tightening clip

(7) Lock ring

(8) Tightening ring

### **REMOVAL**

### I - REMOVAL PREPARATION OPERATION

- □ Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (MR 392, 02A, Lifting equipment).
- □ Disconnect the battery (see **Battery**: **Removal Refitting**) (MR 392, 80A, Battery).
- ☐ Remove the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal Refitting, page 29A-9).


# II - OPERATION FOR REMOVAL OF PART CONCERNED

- ☐ Cut the ring (8) and the tightening clip (6) using cutting pliers or a metal saw, taking care not to damage the yoke sleeve.
- ☐ Push back the gaiter (5) to release the driveshaft yoke sleeve.

Remove as much grease as possible.

#### **WARNING**

Never use thinners to clean the components.



☐ Remove the driveshaft yoke sleeve (3).

#### Note:


- Since the driveshaft yoke sleeve does not have a stop tab, it can be removed without being forced.
- Do not remove the rollers from their respective bushings as the rollers and needles are matched and should never be interchanged.

## Front right-hand driveshaft gaiter, gearbox side: Removal - Refitting

DP0 or JH3 or JR5 or TL4



☐ Remove the lock ring (7) using the tool.



☐ Extract the spider (9), using a press and a releasing type extractor.

#### Noto


Mark the position of the spider before extracting it.

☐ Remove the propeller shaft gaiter.

## **REFITTING**

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the small tightening clip (6) to the propeller shaft.
- ☐ Slightly lubricate the propeller shaft to facilitate fitting the gaiter.
- ☐ Refit the propeller shaft gaiter.



109410

☐ Refit the spider (9) in the position marked during removal.


AFIS

orbov cido: Romavel Refitting

294

Front right-hand driveshaft gaiter, gearbox side: Removal - Refitting

DP0 or JH3 or JR5 or TL4



- 109411
- ☐ Refit the retaining lock ring (7) or crimp at three points at 120° by folding the metal of the splines down onto the propeller shaft.
- ☐ Lubricate the driveshaft yoke sleeve (3).
- ☐ Fit the driveshaft yoke sleeve (3) onto the spider.
- ☐ Divide the quantity of grease between the gaiter (5) and the driveshaft yoke sleeve (3).

#### Note:

Be sure to observe the prescribed quantity of lubricant.

- ☐ Position the lips of the gaiter (5) in the grooves of the driveshaft yoke sleeve and the propeller shaft.
- ☐ Insert a smooth rod with a rounded end between the gaiter and propeller shaft to control the amount of air inside the joint.
- ☐ Refit the clips, tightening with tool (Tav. 1168).

### **II - FINAL OPERATION.**


- □ Refit the front right-hand driveshaft (see 29A, Driveshafts, Front right-hand driveshaft: Removal -Refitting, page 29A-9).
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).

## Front left-hand driveshaft gaiter, gearbox side: Removal - Refitting



DP0 or JH3 or JR5 or TL4

## Special tooling required Tav. 1168 "Clic" type clip pliers for driveshafts with a thermoplastic gaiter.



109401

(1)	Tightening clip
(2)	Tightening ring
(3)	Cup
(4)	Driveshaft yoke sleeve
(5)	Deflector
(6)	Propeller shaft
<b>(7</b> )	RC gaiter
(8)	Spider
(9)	Lock ring
<b>(10)</b>	Spring

## **REMOVAL**

#### I - REMOVAL PREPARATION OPERATION


- ☐ Position the vehicle on a two-post lift (see **Vehicle**: Towing and lifting) (MR 392, 02A, Lifting equipment).
- ☐ Disconnect the battery (see Battery: Removal Refitting) (MR 392, 80A, Battery).
- ☐ Remove the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2).

### **II - OPERATION FOR REMOVAL OF PART CONCERNED**

- ☐ Cut the clip (1) and tightening ring (2) using cutting pliers or a metal saw, taking care not to damage the driveshaft yoke sleeve.
- ☐ Push back the gaiter (7) to release the driveshaft yoke sleeve.
- ☐ Remove as much grease as possible.

#### **WARNING**

Never use thinners to clean the components.



109408

☐ Remove the driveshaft yoke sleeve (4).

#### Note:


- since the driveshaft yoke sleeve does not have a stop tab, it can be removed without being forced.
- Do not remove the rollers from their respective bushings as the rollers and needles are matched and should never be interchanged.

## Front left-hand driveshaft gaiter, gearbox side: Removal - Refitting

DP0 or JH3 or JR5 or TL4



☐ Remove the lock ring (9).



## Note:

Mark the position of the spider before extracting it.


Extract the spider (8), using a press and a releasing type extractor.

☐ Remove the propeller shaft gaiter.

## **REFITTING**

# I - REFITTING OPERATION FOR PART CONCERNED

- ☐ Fit the small tightening clip (1) to the propeller shaft.
- ☐ Slightly lubricate the driveshaft to facilitate fitting gaiter (7).




☐ Refit the spider (8) in the position marked during removal.

29A

Front left-hand driveshaft gaiter, gearbox side: Removal - Refitting

DP0 or JH3 or JR5 or TL4



109411

- ☐ Refit the lock ring (9).
- ☐ Lubricate the driveshaft yoke sleeve (4).
- ☐ Fit the driveshaft yoke sleeve (4) onto the spider.
- ☐ Divide the quantity of grease between the gaiter (7) and the driveshaft yoke sleeve (4).

### Note:

Be sure to observe the prescribed quantity of lubricant (see ) .

- ☐ Position the lips of the gaiter (7) in the grooves of the driveshaft yoke sleeve and the propeller shaft.
- ☐ Insert a smooth rod with a rounded end between the gaiter and propeller shaft to control the amount of air inside the joint.
- ☐ Fit the clips, tightening with the (Tav. 1168).

## II - FINAL OPERATION.

- □ Refit the front left-hand driveshaft (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-2).
- ☐ Connect the battery (see **Battery: Removal Refitting**) (MR 392, 80A, Battery).